



---

---

## **Diagnostic Trouble Code (DTC) Guide for Omnitek ECM 64A/66A/88A**

---

---

---

Omnitek Engineering Corp. – 1333 Keystone Way, #101 – Vista, CA 92081  
Tel. 760-591-0089 - Fax. 760-591-0880 - [www.omnitekcorp.com](http://www.omnitekcorp.com)



---

Comments, questions or reporting of any errors found regarding this document are welcome and appreciated.  
Please direct them to:

Omnitek Engineering, Corp.  
1945 S. Rancho Santa Fe Rd.  
San Marcos, CA 92078 - USA  
+1-760-591-0089 Tel.  
+1-760-591-0880 Fax.

[support@omnitekcorp.com](mailto:support@omnitekcorp.com)

---

# TABLE OF CONTENTS

---

TABLE OF CONTENTS.....	ii
<b>1 INTRODUCTION .....</b>	<b>1</b>
<b>2 DTC TYPE DEFINITION.....</b>	<b>2</b>
<b>2.1 Trip Logic.....</b>	<b>2</b>
<b>2.2 DTC Type A1.....</b>	<b>3</b>
<b>2.3 DTC Type A2.....</b>	<b>3</b>
<b>2.4 DTC Type B.....</b>	<b>3</b>
<b>2.5 DTC Type B3.....</b>	<b>3</b>
<b>2.6 DTC Type C1.....</b>	<b>4</b>
<b>2.7 DTC Type C2.....</b>	<b>4</b>
<b>2.8 DTC Type C3.....</b>	<b>4</b>
<b>2.9 DTC Type X.....</b>	<b>4</b>
<b>2.10 DTC Type Y.....</b>	<b>4</b>
<b>2.11 DTC Status Update Logic.....</b>	<b>5</b>
2.11.1 DTC Conditions Met .....	5
2.11.2 Trip Conditions Met .....	5
2.11.3 ECM Key-Off / Powerdown Sequence.....	5
<b>2.12 Snapshot Logic .....</b>	<b>6</b>
<b>2.13 Malfunction Indicator Lamp Logic.....</b>	<b>6</b>
<b>2.14 End Of Line / Repaired Vehicle DTC Check.....</b>	<b>7</b>
<b>3 DIAGNOSTIC TROUBLE CODE GUIDE .....</b>	<b>8</b>
<b>3.1 DTC P0006 Fuel Shutoff A Solenoid Circuit Low .....</b>	<b>8</b>
<b>3.2 DTC P0007 Fuel Shutoff A Solenoid Circuit High .....</b>	<b>8</b>
<b>3.3 DTC P0031 Oxygen Sensor 1, Bank 1, Heater Low.....</b>	<b>9</b>
<b>3.4 DTC P0032 Oxygen Sensor 1, Bank 1, Heater High.....</b>	<b>10</b>
<b>3.5 DTC P0037 Oxygen Sensor 2, Bank 1, Heater Low.....</b>	<b>11</b>
<b>3.6 DTC P0038 Oxygen Sensor 2, Bank 1, Heater High.....</b>	<b>12</b>
<b>3.7 DTC P0051 Oxygen Sensor 1, Bank 2, Heater Low.....</b>	<b>12</b>

---

3.8 DTC P0052	Oxygen Sensor 1, Bank 2, Heater High .....	13
3.9 DTC P0057	Oxygen Sensor 2, Bank 2, Heater Low .....	14
3.10 DTC P0058	Oxygen Sensor 2, Bank 2, Heater High .....	15
3.11 DTC P0068	MAP/MAF/Throttle Position Correlation .....	15
3.12 DTC P0087	Fuel Rail/System Pressure Too Low.....	16
3.13 DTC P0088	Fuel Rail/System Pressure Too High.....	17
3.14 DTC P0093	Large Fuel Rail Leak .....	18
3.15 DTC P0094	Small Fuel Rail Leak.....	19
3.16 DTC P0102	Mass Air Flow Sensor Low .....	20
3.17 DTC P0103	Mass Air Flow Sensor High .....	21
3.18 DTC P0107	Manifold Absolute Pressure Sensor Low.....	22
3.19 DTC P0108	Manifold Absolute Pressure Sensor High.....	23
3.20 DTC P0112	Intake Air Temperature Sensor Low .....	24
3.21 DTC P0113	Intake Air Temperature Sensor High .....	25
3.22 DTC P0117	Engine Coolant Temperature Sensor Low .....	25
3.23 DTC P0118	Engine Coolant Temperature Sensor High .....	26
3.24 DTC P0122	Throttle Position Sensor Low.....	27
3.25 DTC P0123	Throttle Position Sensor High.....	28
3.26 DTC P0125	Insufficient Coolant Temperature for Closed-Loop .....	29
3.27 DTC P0126	Insufficient Coolant Temperature for Stable Operation.....	30
3.28 DTC P0127	Intake Air Temperature Too High.....	31
3.29 DTC P0128	Thermostat Performance .....	32
3.30 DTC P0129	Barometric Pressure Too Low .....	33
3.31 DTC P0131	Oxygen Sensor 1, Bank 1, Voltage Low .....	33
3.32 DTC P0132	Oxygen Sensor 1, Bank 1, Voltage High .....	34
3.33 DTC P0133	Oxygen Sensor 1, Bank 1, Sluggish .....	35
3.34 DTC P0134	Oxygen Sensor 1, Bank 1, Inactivity.....	36
3.35 DTC P0137	Oxygen Sensor 2, Bank 1 Voltage Low .....	37
3.36 DTC P0138	Oxygen Sensor 2, Bank 1, Voltage High .....	37
3.37 DTC P0139	Oxygen Sensor 2, Bank 1, Slow response.....	38
3.38 DTC P0140	Oxygen Sensor 2, Bank 1, Inactivity.....	39
3.39 DTC P0182	Fuel Temperature Sensor Low .....	40
3.40 DTC P0183	Fuel Temperature Sensor High .....	41

---

---

3.41 DTC P0192	Fuel Rail Pressure Sensor Low.....	42
3.42 DTC P0193	Fuel Rail Pressure Sensor High.....	42
3.43 DTC P0217	Engine Overheat.....	43
3.44 DTC P0219	Engine Over Speed .....	44
3.45 DTC P0222	Throttle Position Sensor B Low .....	44
3.46 DTC P0223	Throttle Position Sensor B High .....	45
3.47 DTC P0234	Engine Over Boost Condition .....	46
3.48 DTC P0236	Boost Pressure Sensor Performance.....	47
3.49 DTC P0237	Boost Pressure Sensor Low .....	48
3.50 DTC P0238	Boost Pressure Sensor High.....	49
3.51 DTC P0245	Turbocharger Wastegate Solenoid Circuit Low .....	50
3.52 DTC P0246	Turbocharger Wastegate Solenoid Circuit High.....	51
3.53 DTC P0261	Injector 1 Circuit Low .....	52
3.54 DTC P0262	Injector 1 Circuit High .....	53
3.55 DTC P0263	Injector 1 Contribution/Balance .....	54
3.56 DTC P0264	Injector 2 Circuit Low .....	54
3.57 DTC P0265	Injector 2 Circuit High .....	55
3.58 DTC P0266	Injector 2 Contribution/Balance .....	56
3.59 DTC P0267	Injector 3 Circuit Low .....	57
3.60 DTC P0268	Injector 3 Circuit High .....	58
3.61 DTC P0269	Injector 3 Contribution/Balance .....	59
3.62 DTC P0270	Injector 4 Circuit Low .....	60
3.63 DTC P0271	Injector 4 Circuit High .....	61
3.64 DTC P0272	Injector 4 Contribution/Balance .....	62
3.65 DTC P0273	Injector 5 Circuit Low .....	63
3.66 DTC P0274	Injector 5 Circuit High .....	64
3.67 DTC P0275	Injector 5 Contribution/Balance .....	65
3.68 DTC P0276	Injector 6 Circuit Low .....	65
3.69 DTC P0277	Injector 6 Circuit High .....	66
3.70 DTC P0278	Injector 6 Contribution/Balance .....	67
3.71 DTC P0279	Injector 7 Circuit Low .....	68
3.72 DTC P0280	Injector 7 Circuit High .....	69
3.73 DTC P0281	Injector 7 Contribution/Balance .....	70

---

---

3.74 DTC P0282	Injector 8 Circuit Low .....	71
3.75 DTC P0283	Injector 8 Circuit High .....	72
3.76 DTC P0284	Injector 8 Contribution/Balance .....	73
3.77 DTC P0297	Vehicle Over Speed .....	74
3.78 DTC P0300	Random Misfire .....	74
3.79 DTC P0301	Misfire, Cylinder 1 .....	76
3.80 DTC P0302	Misfire, Cylinder 2 .....	77
3.81 DTC P0303	Misfire, Cylinder 3 .....	79
3.82 DTC P0304	Misfire, Cylinder 4 .....	80
3.83 DTC P0305	Misfire, Cylinder 5 .....	81
3.84 DTC P0306	Misfire, Cylinder 6 .....	83
3.85 DTC P0307	Misfire, Cylinder 7 .....	84
3.86 DTC P0308	Misfire, Cylinder 8 .....	86
3.87 DTC P0313	Misfire Detected with Low Fuel .....	87
3.88 DTC P0327	Knock Sensor 1 Low .....	88
3.89 DTC P0328	Knock Sensor 1 High .....	89
3.90 DTC P0332	Knock Sensor 2 Low .....	90
3.91 DTC P0333	Knock Sensor 2 High .....	91
3.92 DTC P0335	Crankshaft Position Sensor Circuit Fault .....	92
3.93 DTC P0340	Camshaft Position Sensor Fault .....	93
3.94 DTC P0420	Catalyst System Low Efficiency .....	94
3.95 DTC P0462	Fuel Quantity Sensor Low .....	94
3.96 DTC P0463	Fuel Quantity Sensor High .....	95
3.97 DTC P0502	Vehicle Speed Sensor Low .....	96
3.98 DTC P0503	Vehicle Speed Sensor High or Erratic .....	97
3.99 DTC P0506	Idle Control System RPM Too Low .....	98
3.100 DTC P0507	Idle Control System RPM Too High .....	99
3.101 DTC P0508	Idle Air Control Circuit Low .....	100
3.102 DTC P0509	Idle Speed Control Circuit High .....	101
3.103 DTC P0522	Engine Oil Pressure Sensor Low .....	101
3.104 DTC P0523	Engine Oil Pressure Sensor High .....	102
3.105 DTC P0524	Engine Oil Pressure Low .....	103
3.106 DTC P0530	Air Conditioning Pressure Sensor Circuit Error .....	103

---

---

3.107 DTC P0534	Air Conditioning Refrigerant Loss.....	104
3.108 DTC P0545	Exhaust Temperature Sensor Low .....	105
3.109 DTC P0546	Exhaust Temperature Sensor High .....	105
3.110 DTC P0561	System Voltage Unstable .....	106
3.111 DTC P0562	System Voltage Low .....	107
3.112 DTC P0563	System Voltage High.....	107
3.113 DTC P0603	Keep-Alive Memory Fault .....	108
3.114 DTC P0604	RAM Fault.....	108
3.115 DTC P0605	Flash/ROM Fault .....	109
3.116 DTC P0606	ECM Fault.....	109
3.117 DTC P0615	Starter Control Relay Circuit .....	110
3.118 DTC P0622	Alternator Field Current Monitor Fault .....	110
3.119 DTC P0636	Power Steering Control Relay Circuit Open .....	111
3.120 DTC P0637	Power Steering Control Relay Circuit Shorted .....	111
3.121 DTC P0638	Throttle Control Performance .....	112
3.122 DTC P0642	Sensor Reference Voltage A Low .....	113
3.123 DTC P0643	Sensor Reference Voltage A High .....	114
3.124 DTC P0646	A/C Control Relay Circuit Open .....	114
3.125 DTC P0647	A/C Control Relay Circuit Shorted.....	115
3.126 DTC P0650	Malfunction Indicator Lamp Circuit Fault.....	115
3.127 DTC P0652	Sensor Reference Voltage B Low .....	116
3.128 DTC P0653	Sensor Reference Voltage B High .....	117
3.129 DTC P0654	Engine Speed Output Circuit Fault.....	117
3.130 DTC P0655	Overheat Lamp Circuit Fault .....	118
3.131 DTC P0656	Fuel Level Output Circuit Fault .....	118
3.132 DTC P0657	Actuator Power Control Relay Circuit Open .....	119
3.133 DTC P0658	Actuator Power Voltage Low.....	119
3.134 DTC P0659	Actuator Power Voltage High.....	120
3.135 DTC P0686	Power Control Relay Circuit Low.....	121
3.136 DTC P0687	Power Control Relay Circuit High.....	122
3.137 DTC P0691	Fan 1 Relay Control Circuit Low .....	122
3.138 DTC P0692	Fan 1 Relay Control Circuit High .....	123
3.139 DTC P0693	Fan 2 Relay Control Circuit Low .....	124

---



---

3.140 DTC P0694	Fan 2 Relay Control Circuit High .....	124
3.141 DTC P0695	Fan 3 Relay Control Circuit Low .....	125
3.142 DTC P0696	Fan 3 Relay Control Circuit High .....	126
3.143 DTC P0698	Sensor Reference Voltage C Low .....	126
3.144 DTC P0699	Sensor Reference Voltage C High .....	127
3.145 DTC P1134	Oxygen Sensor 1, Bank 1, Erratic Air-Fuel Ratio .....	128
3.146 DTC P1135	Oxygen Sensor 1, Bank 1, Oxygen Sensor Lean Shift.....	129
3.147 DTC P1136	Oxygen Sensor 1, Bank 1, Oxygen Sensor Rich Shift .....	130
3.148 DTC P1137	Oxygen Sensor 1, Bank 1, Oxygen Sensor High Impedance .....	131
3.149 DTC P1138	Oxygen Sensor 1, Bank 1, Oxygen Sensor Overheat Condition.....	132
3.150 DTC P1517	Backup TPS Data Does Not Match.....	133
3.151 DTC P1518	Unable to complete throttle zero process.....	134
3.152 DTC P1519	No Backup TPS Zero Data Found .....	135
3.153 DTC P1520	No Primary TPS Zero Data Found.....	135
3.154 DTC P1521	Throttle Resting Position Incorrect .....	136
3.155 DTC P1522	Throttle Resting Position Incorrect After Span .....	137
3.156 DTC P1524	Low Oil Pressure Lamp Circuit Fault.....	138
3.157 DTC P1525	Customer-Specific Lamp Circuit A Fault.....	138
3.158 DTC P1526	Customer-Specific Lamp Circuit B Fault.....	139
3.159 DTC P1560	Low Coolant Level Lamp Circuit Fault .....	140
3.160 DTC P1609	Calibration/Firmware Mismatch .....	140
3.161 DTC P1630/P1631	Electronic Throttle Driver Overheat .....	141
3.162 DTC P1632	Electronic Throttle Driver Overheat Shutdown .....	141
3.163 DTC P1633	Electronic Throttle Driver Overvoltage Shutdown .....	142
3.164 DTC P1655	Coolant Temperature Output Circuit Fault.....	143
3.165 DTC P1656	Low Fuel Lamp Circuit Fault .....	143
3.166 DTC P1657	Stop Engine Lamp Circuit Fault.....	144
3.167 DTC P1661	Internal Power Supply Voltage Low.....	145
3.168 DTC P1662	Internal Power Supply Voltage High.....	145
3.169 DTC P1666	Fuel Shutoff C Solenoid Circuit Low .....	145
3.170 DTC P1667	Fuel Shutoff C Solenoid Circuit High .....	146
3.171 DTC P1690	Maintenance Reminder .....	147
3.172 DTC P2096	Post Catalyst Fuel Trim System Too Lean.....	147

---

---

3.173 DTC P2097	Post Catalyst Fuel Trim System Too Rich .....	148
3.174 DTC P2100	Throttle Actuator Control Motor Circuit Open .....	150
3.175 DTC P2102	Throttle Actuator Control Motor Circuit Low .....	150
3.176 DTC P2103	Throttle Actuator Control Motor Circuit High .....	151
3.177 DTC P2111	Throttle Stuck Open .....	152
3.178 DTC P2112	Throttle Stuck Closed .....	153
3.179 DTC P2122	Accelerator Pedal Position Sensor D Low .....	153
3.180 DTC P2123	Accelerator Pedal Position Sensor D High .....	154
3.181 DTC P2127	Accelerator Pedal Position Sensor E Low .....	155
3.182 DTC P2128	Accelerator Pedal Position Sensor E High .....	156
3.183 DTC P2132	Accelerator Pedal Position Sensor F Low .....	157
3.184 DTC P2133	Accelerator Pedal Position Sensor F High.....	158
3.185 DTC P2135	Throttle Position Sensor A-B Correlation .....	159
3.186 DTC P2138	Accelerator Pedal Position Sensor D-E Correlation .....	160
3.187 DTC P2139	Accelerator Pedal Position Sensor D-F Correlation.....	161
3.188 DTC P2139	Accelerator Pedal Position Sensor E-F Correlation.....	161
3.189 DTC P2172	Sudden High Airflow Detected .....	162
3.190 DTC P2173	High Airflow Detected .....	163
3.191 DTC P2174	Sudden Low Airflow Detected.....	164
3.192 DTC P2175	Low Airflow Detected .....	165
3.193 DTC P2176	Idle Position Not Learned .....	166
3.194 DTC P2177	Fuel System Too Lean off-Idle, Bank 1.....	167
3.195 DTC P2178	Fuel System Too Rich off-Idle, Bank 1 .....	168
3.196 DTC P2187	Fuel System Too Lean at Idle, Bank 1 .....	169
3.197 DTC P2188	Fuel System Too Rich at Idle, Bank 1.....	170
3.198 DTC P2191	Fuel System Too Lean At High Load, Bank 1 .....	171
3.199 DTC P2192	Fuel System Too Rich At High Load, Bank 1.....	172
3.200 DTC P2195	Oxygen Sensor 1, Bank 1, Signal Stuck Lean .....	173
3.201 DTC P2196	Oxygen Sensor 1, Bank 1, Signal Stuck Rich.....	174
3.202 DTC P2231	Oxygen Sensor 1, Bank 1, Shorted to Heater .....	175
3.203 DTC P2243	Oxygen Sensor Reference Circuit, Bank 1, Sensor 1 .....	176
3.204 DTC P2261	Turbocharger Bypass Valve – Mechanical.....	176
3.205 DTC P2262	Turbocharger Boost Pressure - Mechanical.....	177

---

---

3.206 DTC P2263	Turbocharger Boost Pressure System Performance.....	178
3.207 DTC P2270	Oxygen Sensor 2, Bank 1, Signal Stuck Lean .....	179
3.208 DTC P2271	Oxygen Sensor 2, Bank 1, Signal Stuck Rich.....	180
3.209 DTC P2297	Oxygen Sensor 1, Bank 1, Signal Stuck Rich During Deceleration.....	181
3.210 DTC P2299	Accelerator Pedal Position Sensor and Brake Switch Incompatible.....	182
3.211 DTC P2300	Ignition Coil 1 Circuit Primary Low Current.....	183
3.212 DTC P2301	Ignition Coil 1 Circuit Primary High Current.....	184
3.213 DTC P2302	Ignition Coil 1 Circuit Secondary Fault .....	184
3.214 DTC P2303	Ignition Coil 2 Circuit Primary Low Current.....	185
3.215 DTC P2304	Ignition Coil 2 Circuit Primary High Current.....	186
3.216 DTC P2305	Ignition Coil 2 Circuit Secondary Fault .....	187
3.217 DTC P2306	Ignition Coil 3 Circuit Primary Low Current.....	188
3.218 DTC P2307	Ignition Coil 3 Circuit Primary High Current.....	188
3.219 DTC P2308	Ignition Coil 3 Circuit Secondary Fault .....	189
3.220 DTC P2309	Ignition Coil 4 Circuit Primary Low Current.....	190
3.221 DTC P2310	Ignition Coil 4 Circuit Primary High Current.....	191
3.222 DTC P2311	Ignition Coil 4 Circuit Secondary Fault .....	191
3.223 DTC P2312	Ignition Coil 5 Circuit Primary Low Current.....	192
3.224 DTC P2313	Ignition Coil 5 Circuit Primary High Current.....	193
3.225 DTC P2314	Ignition Coil 5 Circuit Secondary Fault .....	194
3.226 DTC P2315	Ignition Coil 6 Circuit Primary Low Current.....	195
3.227 DTC P2316	Ignition Coil 6 Circuit Primary High Current.....	195
3.228 DTC P2317	Ignition Coil 6 Circuit Secondary Fault .....	196
3.229 DTC P2318	Ignition Coil 7 Circuit Primary Low Current.....	197
3.230 DTC P2319	Ignition Coil 7 Circuit Primary High Current.....	198
3.231 DTC P2320	Ignition Coil 7 Circuit Secondary Fault .....	198
3.232 DTC P2321	Ignition Coil 8 Circuit Primary Low Current.....	199
3.233 DTC P2322	Ignition Coil 8 Circuit Primary High Current.....	200
3.234 DTC P2323	Ignition Coil 8 Circuit Secondary Fault .....	201
3.235 DTC P2336	Cylinder 1 Above Knock Threshold.....	202
3.236 DTC P2337	Cylinder 2 Above Knock Threshold.....	202
3.237 DTC P2338	Cylinder 3 Above Knock Threshold.....	203
3.238 DTC P2339	Cylinder 4 Above Knock Threshold.....	204

---

---

3.239 DTC P2340	Cylinder 5 Above Knock Threshold.....	205
3.240 DTC P2341	Cylinder 6 Above Knock Threshold.....	206
3.241 DTC P2342	Cylinder 7 Above Knock Threshold.....	207
3.242 DTC P2343	Cylinder 8 Above Knock Threshold.....	208
3.243 DTC P2428	Exhaust Overheat.....	208
3.244 DTC P2560	Engine Coolant Level Low.....	209
3.245 DTC P2626	Oxygen Sensor 1, Bank 1, Trim Circuit Open.....	210
3.246 DTC P2666	Fuel Shutoff B Solenoid Circuit Low.....	210
3.247 DTC P2667	Fuel Shutoff B Solenoid Circuit High.....	211
3.248 DTC U1110	Antitheft Module Triggered.....	212
4	MODE 6 DATA GUIDE.....	213
	APPENDIX A: YOUR ATMOSPHERIC PRESSURE.....	214

---

# 1 INTRODUCTION

---

This document describes diagnostic trouble code (DTC) logic used in the ECM 64A, 66A and 88A Engine Control Module (ECM) from Omnitek Engineering, Corp. Diagnostic trouble codes are used by the engine control module to help identify malfunctioning or unusual equipment or operation. If the calibrator desires, the operator of the vehicle can be notified with the dashboard malfunction indicator lamp (MIL) or other specific-function indicator lamp. While DTC diagnosis is a very powerful tool, the software can only diagnose what it has been programmed to recognize, and the actions taken by the system will depend upon the programming by the calibrator and system integrator. Properly set up, the DTC functions will help diagnose equipment problems, provide useful information to the operator, maintain compliance with exhaust emission legislation, identify abusive operation, and take appropriate protective action before equipment damage occurs. A secondary objective of correct DTC calibration is *not* setting a code or turning on a MIL unless there is a problem significant enough to warrant repair. DTC calibration requires knowing your equipment well enough that the correct balance can be achieved.

The reactive, proactive and protective logic used in response to diagnoses made by the ECM are not necessarily appropriate for all vehicles and engines, and some jurisdictions may require DTC logic or responses different from those reflected in this document. Proper functioning of the DTC logic relies on careful calibration of many parameters which vary between end-user applications.

Engine damage, component damage or non-compliant exhaust emissions may result from improper calibration or inappropriate control logic for specific needs.

It is the responsibility of the calibrator to ensure that DTC calibration and logic meet the needs of the application and the requirements of the law. We disclaims all responsibility for damages or consequences of DTC's and associated software that arise from use of the ECM.

The limits shown in this document are typical limits, for specific vehicle applications, these numbers may be modified in the diagnostic system calibration.

---

## 2 DTC TYPE DEFINITION

---

### 2.1 Trip Logic

A trip consists of sufficient vehicle operation to run its various diagnostic monitors. Four trip flags are used in the ECM.

A quick trip consists of:

- At least 45 seconds of engine running time
- At least 10 seconds with one of:
  - greater than 60 kPa<sub>a</sub> manifold pressure OR
  - greater than 15% desired torque (electronic throttle systems only) OR
  - vehicle speed greater than 25 km/h

A normal trip consists of:

- at least four minutes of loaded operation with one of:
  - greater than 60 kPa<sub>a</sub> manifold pressure OR
  - greater than 15% desired torque (electronic throttle systems only) OR
  - vehicle speed greater than 25 km/h
- at least two minutes of idle operation after at least one minute of loaded operation
- an engine start and an engine stop cycle
- Start coolant temperature lower than 50 degrees C
- Achieves a coolant temperature of at least 65 degrees C
- At least ten minutes of run time

An oxygen sensor trip also adds sufficient time to the generic trip to accumulate 256 rich-lean cycles at a steady state.

An oxygen sensor impedance check trip also adds a test completion flag to the generic trip rules.

Note that a 'trip' is used in the diagnostic logic regardless of if some test conditions are not met – this tends to reduce the likelihood of the malfunction lamp illuminating for non-critical faults, and also facilitates earlier lamp extinguishing. For EOBD compliance, this logic will need to be modified so that each diagnostic trouble code has its own trip conditions.



---

## 2.2 DTC Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## 2.3 DTC Type A2

- Emissions related
- Stores freeze-frame data at time of fault
- MIL will illuminate after completion of the first quick trip with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## 2.4 DTC Type B

- Emissions related
- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## 2.5 DTC Type B3

- Emissions related – MIL circuit fault only
- On trip with first fault, pending DTC stored
- DTC will clear after forty consecutive normal trips without a fault
- This DTC type is only utilized for MIL circuit faults where the MIL cannot be illuminated.

---

## 2.6 DTC Type C1

- Not emissions related
- Immediate DTC set
- Immediate MIL illumination
- No freeze-frame data will be stored
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## 2.7 DTC Type C2

- Not emissions related
- On quick trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive quick trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## 2.8 DTC Type C3

- Not emissions related
- Current DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

## 2.9 DTC Type X

- This DTC has been disabled and will not appear on a scan tool
- Backup or alternative operating strategies will still be enabled when this fault is detected

## 2.10 DTC Type Y

- In the case of a catalyst-damaging misfire, the Malfunction Indicator Lamp will flash at 1 Hz.
- This will appear on a scan tool as a pending DTC until the misfire diagnostic logic determines that a type A or B DTC is required.



---

## 2.11 DTC Status Update Logic

DTC updates are performed at specific times during the ECM's operation. The operation of the diagnostic logic is in line with OBD-II and EOBD guidelines. The operation of these is summarized as follows:

### 2.11.1 DTC Conditions Met

When the DTC conditions are met (the moment the monitor logic detects a fault), a pending DTC will be set for all DTC's except for types A1 and C1. For types A1 and C1, a current DTC will be set. The DTC update/erase counter will be cleared. If a pending DTC was already present, a flag is set so that during the next power-down cycle, the fault status will be changed to current.

### 2.11.2 Trip Conditions Met

When the trip conditions are met, a flag is set that indicates that the current engine key cycle contained at least one valid trip. No specific actions are performed at this time.

### 2.11.3 ECM Key-Off / Powerdown Sequence

When the ECM powers down, the following events occur:

- The ECM turns off injector and fuel solenoid signals to stop the engine
- The idle air control motor (if used) is re-zeroed
- The throttle span (on ETC systems) is checked and if required, a zero cycle is performed
- All nonvolatile items are written to EEPROM including the current DTC status. TRIP STATUS is not reflected in this update.
- If configured, a fuel leakage check is performed by the ECM. This can take up to ten minutes.
- If configured, the catalyst temperature model is maintained until the estimated catalyst temperature drops within 16 degrees C of engine coolant temperature.
- If a valid quick trip has occurred, the following actions are performed:
  - If a pending DTC has been set in this key cycle with type A2, the ECM will change the fault status to a current fault. The MIL will illuminate at the next engine start.
  - If a pending DTC has been set in this key cycle with a type other than A2, AND the DTC was previously in a pending state, the ECM will change the fault status to a current fault. The MIL will illuminate at the next engine start.
- If a valid normal trip has occurred, the following actions are performed
  - If a pending DTC has not been set in this key cycle, but a pending DTC is present in the DTC memory, a counter is incremented. If this counter reaches two, the DTC is cleared from memory.

- 
- If a current DTC is present, the DTC clear counter is incremented. If the counter reaches two, the DTC status is changed to history. If this DTC was causing the MIL to be on, it will remain off at the next engine start cycle.
  - If a history DTC is present, the DTC clear counter is incremented. If the counter reaches 40, the DTC is erased from memory. The associated snapshot (if any) is erased at the same time.
- The DTC memory is written to EEPROM.
  - The ECM will now power down.

If the key switch is turned on before these events have finished, the process is stopped and the diagnostic memory is maintained. No trip DTC logic will be run until the next key-off cycle.

## 2.12 Snapshot Logic

A snapshot / freeze-frame is stored when the conditions to set a DTC occur, subject to the DTC rules described in the appropriate DTC type section. Different engine management controllers have a different snapshot storage capacity. Most ECM controllers are equipped with a storage capacity of four snapshots. The conditions for updating the snapshots are:

- A DTC may have only one snapshot. A recurrence of the same DTC will result in updating the snapshot data.
- Snapshots are cleared when a DTC clear command is issued from a scan tool.
- Snapshots are cleared when the DTC is erased from memory. It is not cleared when the DTC changes from current to history.
- Once the snapshot memory is full, no further snapshots will be stored. Existing DTC snapshots will be updated.

## 2.13 Malfunction Indicator Lamp Logic

The MIL will illuminate during key-on, engine-off conditions as a bulb check. After starting, it will extinguish for at least one second to perform a MIL diagnostic test.

If any current DTC is present that is commanded to turn on the MIL, it will remain on during engine running conditions.

The platform-specific calibration system may disable the MIL on any faults that would otherwise enable it. If a DTC is set up in this manner, all trip functions and current/pending status updates will occur as described, but the MIL will not illuminate. Type B3 and C3 DTC's cannot be forced to illuminate the MIL so will never result in an illuminated MIL.

If a catalyst-damaging misfire has been detected, the MIL will flash at 1 Hz.

While in firmware update mode, some engine management systems will flash the MIL at a higher frequency.

---

## 2.14 End Of Line / Repaired Vehicle DTC Check

In order to verify proper vehicle operation either at the end of the manufacturing process, or after repairs have been performed to a vehicle, it is recommended to operate the vehicle for several minutes while most system checks are performed. An entire trip does not need to be done for most DTC's, however; some faults will take a long time to detect. To facilitate troubleshooting, each fault code is listed with a set of conditions required to trigger a DTC.

After a drive cycle has been done, no pending or current DTC's should be found. If a pending fault is found at an EOL test condition, that sensor or system should be checked for proper operation and serviced, if required. Note that the MIL will not illuminate for pending DTC's, so a scan tool must be used to check for fault codes.

---

## 3 DIAGNOSTIC TROUBLE CODE GUIDE

---

### 3.1 DTC P0006 Fuel Shutoff A Solenoid Circuit Low

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set. In many cases, the vehicle will not operate when this fault is present as no fuel will be delivered to the engine.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Actuator power above 10 volts
- Fuel Shutoff Solenoid A commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.

### 3.2 DTC P0007 Fuel Shutoff A Solenoid Circuit High

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set. In many cases, the vehicle will not operate when this fault is present as no fuel will be delivered to the engine.

---

---

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Actuator power above 10 volts
- Fuel shutoff solenoid A output commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.

### **3.3 DTC P0031 Oxygen Sensor 1, Bank 1, Heater Low**

The ECM is designed to utilize either a four-wire planar oxygen sensor or a Bosch UEGO. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to ground, an open-circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Key power voltage greater than 6 volts
- Actuator power above 10 volts
- Oxygen sensor heater duty cycle in off time period
- Output driver IC records low voltage fault (short to ground or open load)

- 
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check heater continuity. If open, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.

### **3.4 DTC P0032 Oxygen Sensor 1, Bank 1, Heater High**

The ECM is designed to utilize a four-wire planar oxygen sensor or a Bosch UEGO. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to power.

Flash code: none

Conditions to run test, UEGO or planar sensor:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Key power voltage greater than 6 volts
- Oxygen sensor heater duty cycle in on time period
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

OR Conditions to run test, UEGO sensor only:

- Sensor resistance below 75 ohms
- Condition exists for 15 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check heater continuity. If below 3 ohms, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.
- Check wiring for short circuits.

### **3.5 DTC P0037    Oxygen Sensor 2, Bank 1, Heater Low**

The ECM is designed to utilize a four-wire planar oxygen sensor. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to ground, an open-circuit or blown fuse. This fault code is only enabled for systems with post-catalyst oxygen sensors.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Key power greater than 6 volts
- Actuator power above 10 volts
- Oxygen sensor heater duty cycle in off time period
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check heater continuity. If open, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.



---

### 3.6 DTC P0038 Oxygen Sensor 2, Bank 1, Heater High

The ECM is designed to utilize a four-wire planar oxygen sensor. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to power. This fault code is only enabled for systems with post-catalyst oxygen sensors.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Key power voltage greater than 6 volts
- Actuator power above 10 volts
- Oxygen sensor heater duty cycle in on time period
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check heater continuity. If below 3 ohms, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.
- Check wiring for short circuits.

### 3.7 DTC P0051 Oxygen Sensor 1, Bank 2, Heater Low

The ECM is designed to utilize either a four-wire planar oxygen sensor or a Bosch UEGO. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to ground, an open-circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded



- 
- Actuator power relay actuated
  - Key power voltage greater than 6 volts
  - Actuator power above 10 volts
  - Oxygen sensor heater duty cycle in off time period
  - Output driver IC records low voltage fault (short to ground or open load)
  - Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check heater continuity. If open, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.

### **3.8 DTC P0052 Oxygen Sensor 1, Bank 2, Heater High**

The ECM is designed to utilize a four-wire planar oxygen sensor or a Bosch UEGO. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to power.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Key power voltage greater than 6 volts
- Actuator power above 10 volts
- Oxygen sensor heater duty cycle in on time period
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored

- 
- On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check heater continuity. If below 3 ohms, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.
- Check wiring for short circuits.

### 3.9 DTC P0057 Oxygen Sensor 2, Bank 2, Heater Low

The ECM is designed to utilize a four-wire planar oxygen sensor. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to ground, an open-circuit or blown fuse. This fault code is only enabled for systems with post-catalyst oxygen sensors.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Key power greater than 6 volts
- Actuator power above 10 volts
- Oxygen sensor heater duty cycle in off time period
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check heater continuity. If open, replace sensor.
  - Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.
-

---

### 3.10 DTC P0058     Oxygen Sensor 2, Bank 2, Heater High

The ECM is designed to utilize a four-wire planar oxygen sensor. The heater element requires ECM control for proper sensor operation. This fault can occur if the oxygen sensor heater control wire has a short-circuit to power. This fault code is only enabled for systems with post-catalyst oxygen sensors.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Key power voltage greater than 6 volts
- Oxygen sensor heater duty cycle in on time period
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check heater continuity. If below 3 ohms, replace sensor.
- Check power circuit for continuity and fuse integrity. Repair fault and/or fuse.
- Check wiring for short circuits.

### 3.11 DTC P0068     MAP/MAF/Throttle Position Correlation

The fuelling calculator uses a combination of airflow estimators to determine the correct amount of fuel to deliver. These are compared and corrected as part of the fuelling algorithms. Generally, throttle position airflow estimate is most accurate while the throttle is moving, whereas either speed-density (MAP) or mass air flow (MAF) sensors will give the best steady-state accuracy. In order to maintain steady-state agreement, a correction factor is applied to the throttle airflow estimate. If this correction exceeds a reasonable amount, and the pressure across the throttle is sufficient to get a good estimate, this DTC will set.

---

This DTC may indicate a drifted sensor, a contaminated throttle bore, air duct blockage, or air leakage after the throttle. At small throttle openings, this may set if the IAC is not in the correct position.

If this DTC sets during calibration, check the calibration of volumetric efficiency against throttle airflow.

Flash code: none

Conditions to run test:

- Airflow correction factor greater than 180% or below 50%
- An engine load (relative air flow per cylinder charge) value of at least 10%
- Engine running at steady-state or mild transient conditions
- Conditions exist for 5 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Check for contamination of throttle bore and/or IAC.
- Check for proper operation of the IAC. Repair IAC related DTC's first.
- Check for manifold vacuum leakage (gaskets)
- Check for damaged vacuum hoses.

### **3.12 DTC P0087 Fuel Rail/System Pressure Too Low**

This diagnostic trouble code indicates that the fuel rail supply pressure is too low for proper engine operation. Only systems equipped with fuel rail pressure sensors are capable of setting this DTC. At very low fuel pressures, the injectors will not be capable of fuelling the engine, and the system will lean out. In addition, at very low fuel supply pressures, fuel restriction in some fuel mixing assemblies will cause poor or inconsistent fuel flow.

Flash code: none

Conditions to run test:

- Fuel quantity sensor indicates at least 2 MPa pressure.
- Fuel rail pressure below minimum calibrated fuel pressure value.

- 
- No actuator power relay faults recorded
  - No fuel shutoff solenoid faults recorded
  - No sensor power faults recorded
  - No fuel quantity sensor faults recorded

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Monitor fuel rail or regulator inlet pressure during engine operation.
- Ensure regulator is set correctly
- Ensure that no restrictions are present in the fuel system
- Remember that for LPG and CNG systems, much more fuel volume is required, so restrictions that would not even affect a petrol system may make a gaseous fuel system non-functional.

### 3.13 DTC P0088 Fuel Rail/System Pressure Too High

This diagnostic trouble code indicates that the fuel rail supply pressure is too high for proper engine operation. Only systems equipped with fuel rail pressure sensors are capable of setting this DTC. In a CNG system, in many cases excessive fuel pressure will result in injectors that will not open.

Flash code: none

#### Conditions to run test:

- Fuel rail pressure above maximum calibrated fuel pressure value.
- No actuator power relay faults recorded
- No fuel shutoff solenoid faults recorded
- No sensor power faults recorded
- No fuel quantity sensor faults recorded

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored

- 
- After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Monitor fuel rail or regulator inlet pressure during engine operation.
- Ensure regulator is set correctly
- Check regulator for excessive creep (rising pressure when engine is stopped)
- Check regulator for excessive droop (lowering pressure with higher engine speeds and loads)

### 3.14 DTC P0093 Large Fuel Rail Leak

This diagnostic trouble code indicates that the fuel rail has a significant leak path either into the engine (injector leakage), or to the atmosphere. This test is performed occasionally by allowing the ECM to monitor the leak down rate of the fuel storage pressure sensor or the fuel rail pressure sensor, depending on the system configuration and configuration of fuel shutoff solenoids.

Flash code: none

Conditions to run test:

- Fuel quantity sensor indicates at least 3 MPa pressure when the key is turned off.
- Fuel quantity sensor indicates a pressure drop of 1 MPa in a programmed amount of time – typically three minutes.
- No actuator power relay faults recorded
- No fuel shutoff solenoid faults recorded
- No sensor power faults recorded
- No fuel quantity sensor faults recorded

OR

- Fuel rail pressure sensor indicates at least 400 kPa<sub>g</sub> pressure when the key is turned off.
- Fuel rail pressure sensor indicates a pressure drop of 200 kPa<sub>g</sub> in a programmed amount of time – typically three minutes.
- No fuel rail pressure sensor faults recorded
- No fuel level sensor faults recorded
- No actuator power relay faults recorded
- No low-pressure fuel shutoff solenoid faults recorded

DTC Logic: Type B



- 
- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Monitor fuel rail or regulator inlet pressure after shutting the ignition key off.
- Observe source of leakage by testing for the presence of tracer odour and/or a leak detection 'soap bubble' leak finding solution.
- If leakage is outside of the engine (fuel rail, fittings, pressure regulator), find and repair the leakage.
- If no leaks can be found, disconnect the air hose at the throttle, energize the ignition key (to pressurize the fuel rail), and listen and check for the tracer odour at the throttle body for fuel injector leakage. This is usually easiest with the throttle slightly open.

### 3.15 DTC P0094      **Small Fuel Rail Leak**

This diagnostic trouble code indicates that the fuel rail has a small but easily detectable leak path either into the engine (injector leakage), or to the atmosphere. This test is performed occasionally by allowing the ECM to monitor the leak down rate of the fuel storage pressure sensor or the fuel rail pressure sensor, depending on the system configuration and configuration of fuel shutoff solenoids.

Flash code: none

Conditions to run test:

- Fuel quantity sensor indicates at least 3 MPa pressure when the key is turned off.
- Fuel quantity sensor indicates a pressure drop of 1 MPa in a programmed amount of time – typically three minutes.
- No actuator power relay faults recorded
- No fuel shutoff solenoid faults recorded
- No sensor power faults recorded
- No fuel quantity sensor faults recorded

OR

- Fuel rail pressure sensor indicates at least 400 kPa<sub>g</sub> pressure when the key is turned off.
- Fuel rail pressure sensor indicates a pressure drop of 200 kPa<sub>g</sub> in a programmed amount of time – typically three minutes.

- 
- No fuel rail pressure sensor faults recorded
  - No fuel level sensor faults recorded
  - No actuator power relay faults recorded
  - No low-pressure fuel shutoff solenoid faults recorded

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Monitor fuel rail or regulator inlet pressure after shutting the ignition key off.
- Observe source of leakage by testing for the presence of tracer odour and/or a leak detection 'soap bubble' leak finding solution.
- If leakage is outside of the engine (fuel rail, fittings, pressure regulator), find and repair the leakage.
- If no leaks can be found, disconnect the air hose at the throttle, energize the ignition key (to pressurize the fuel rail), and listen and check for the tracer odour at the throttle body for fuel injector leakage. This is usually easiest with the throttle slightly open.

### 3.16 DTC P0102      **Mass Air Flow Sensor Low**

Engine airflow may be measured directly using a mass air flow sensor. The sensor may interface to the ECM using either an analogue voltage, or a digital frequency. A frequency signal is converted into a voltage signal in software for processing by the ECM. This generated voltage signal is used for diagnostic configuration. The engine may stall before the DTC sets.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- MAF signal level below 0.1 volts
- Engine speed above 100 RPM
- Condition exists for 1 seconds.

Actions taken when fault is detected:

- MAP is used to generate a simulated MAF sensor reading OR



- 
- Throttle position is used to generate a simulated MAF sensor reading
  - Long term fuel trim logic is disabled
  - Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check +12V power supply to MAF sensor. If absent, repair wiring and/or fuse.
- Check for continuity of the MAF sensor signal and the ECM. If absent, repair wiring.
- Check output of MAF with a voltmeter and jumper wires.

### 3.17 DTC P0103     **Mass Air Flow Sensor High**

Engine airflow may be measured directly using a mass air flow sensor. The sensor may interface to the ECM using either an analogue voltage, or a digital frequency. A frequency signal is converted into a voltage signal in software for processing by the ECM. This generated voltage signal is used for diagnostic configuration. The engine may stall before the DTC sets.

Flash code : none

Conditions to run test:

- MAF signal level above 4.95 volts
- Engine running above 100 RPM
- No sensor power supply faults recorded
- Condition exists for 1.0 seconds.

Actions taken when fault is detected:

- MAP is used to generate a simulated MAF sensor reading OR
- Throttle position is used to generate a simulated MAF sensor reading
- Long term fuel trim logic is disabled
- Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

- Immediate DTC stored
-

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check +12V power supply to MAF sensor. If absent, repair wiring and/or fuse.
- Check sensor ground wire to MAF sensor. If absent, repair wiring.
- Is an IATS fault also recorded? If so, verify sensor ground to MAF sensor.
- Check for continuity of the MAF sensor signal and the ECM. If absent, repair wiring.
- Check output of MAF with a voltmeter and jumper wires.

### 3.18 DTC P0107     **Manifold Absolute Pressure Sensor Low**

Engine airflow is estimated based on the pressure in the intake manifold. If the sensor becomes disconnected or fails in a short-to-ground condition, this fault will set. The engine may stall before the DTC sets.

The engine stopped low MAP DTC may set if the engine speed signal is interrupted while the engine is still running.

Flash code: none

Conditions to run test:

- Engine Running Test:
  - No sensor power supply fault recorded
  - MAP signal level below 0.05 volts
  - Engine speed below 6000 RPM
  - OR throttle position greater than 10%
  - Condition exists for 1.0 seconds
- Engine Stopped Test:
  - MAP sensor reading below 70 kPa<sub>a</sub>
  - No engine speed signal
  - No sensor power supply fault recorded
  - Condition exists for 1.0 seconds

Actions taken when fault is detected:

- Throttle position is used to generate a simulated MAP sensor reading OR

- 
- Mass air flow sensor is used to generate a simulated MAP sensor reading
  - Long term fuel trim logic is disabled
  - Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply DTC's. If present, troubleshoot those DTC's first.
- Check for +5 V power at the MAP sensor. If not present, check wiring.
- Connect +5 V sensor power to MAP sensor input. View MAP sensor reading and verify that value is high (above 100 kPa<sub>a</sub>), or that the MAP sensor voltage reads 5 V. If not, check sensor wiring.
- Check MAP sensor output. If no output, replace MAP sensor.

### **3.19 DTC P0108      Manifold Absolute Pressure Sensor High**

Engine airflow is estimated based on the pressure in the intake manifold. If the sensor fails in a short-to-power condition, or if the sensor ground signal becomes disconnected, this fault will set. The engine may stall before the DTC sets.

Flash code : none

Conditions to run test:

- No sensor power supply fault recorded
- MAP signal level above 4.92 volts
- Condition exists for 1.0 seconds.

Actions taken when fault is detected:

- Throttle position is used to generate a simulated MAP sensor reading OR
- Mass air flow sensor is used to generate a simulated MAP sensor reading
- Long term fuel trim logic is disabled
- Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

---

- 
- Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply DTC's. If present, troubleshoot those DTC's first.
- Check for +5 V power at the MAP sensor. If not present, check wiring.
- Check sensor ground at the MAP sensor. If no continuity, repair wiring.
- If combined T-MAP sensor and IATS fault is present, repair sensor ground.
- Check MAP sensor output. If no output, replace MAP sensor.

### 3.20 DTC P0112 Intake Air Temperature Sensor Low

Engine airflow estimation and ignition timing require a measurement of the temperature of the incoming air. A short to ground on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- IATS signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected:

- Intake air temperature uses a calculated substitute value

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V. If not, check wiring for short circuit to ground or adjacent terminals.
- Check resistance of sensor. Verify that it is within specifications.

---

### 3.21 DTC P0113 Intake Air Temperature Sensor High

Engine airflow estimation and ignition timing require a measurement of the temperature of the incoming air. An open circuit or a short circuit to power on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- IATS signal above 4.85 volts
- Condition exists for one second

Actions taken when fault is detected:

- Intake air temperature uses a calculated substitute value

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V.
- Jumper across IATS harness sensor (sensor ground to IATS). Verify temperature sensor voltage reads 0 V. If not, check harness for continuity.
- Check resistance of sensor. Verify that it is within specifications.

### 3.22 DTC P0117 Engine Coolant Temperature Sensor Low

Engine airflow estimation, cooling fan control, and ignition timing require a measurement of the temperature of the engine coolant. A short to ground on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- ECTS signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected:

- Engine coolant temperature uses a calculated substitute value
- Engine cooling fan is turned on

- 
- Air conditioning system is disabled
  - Long-term fuel trims are disabled
  - Trip logic will not utilize engine coolant temperature in its calculations

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V. If not, check wiring for short circuit to ground or adjacent terminals.
- Check resistance of sensor. Verify that it is within specifications.

### 3.23 DTC P0118 Engine Coolant Temperature Sensor High

Engine airflow estimation, cooling fan control, and ignition timing require a measurement of the temperature of the engine coolant. An open circuit or a short circuit to power on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- ECTS signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected:

- Engine coolant temperature uses a calculated substitute value
- Engine cooling fan is turned on
- Air conditioning is disabled
- Long-term fuel trims are disabled
- Trip logic will not utilize engine coolant temperature in its calculations

DTC Logic: Type B

- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
-



- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V.
- Jumper across sensor harness sensor (sensor ground to sensor signal). Verify temperature sensor voltage reads 0 V. If not, check harness for continuity.
- Check resistance of sensor. Verify that it is within specifications.

### 3.24 DTC P0122 Throttle Position Sensor Low

The ECM utilizes throttle position information to predict airflow into the engine during a transient condition, for idle speed control and for many auxiliary functions. In an electronic throttle control (ETC) system, this sensor is used as the primary feedback mechanism to control airflow through the engine. ETC systems will use at least two throttle position sensors for redundancy.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected in non-ETC system

- Engine idle speed is raised to a programmed value (typically, 1300 RPM)
- Intake manifold pressure is utilized for deceleration and transient fuel control
- Idle speed control may be erratic

Actions taken when fault is detected in an ETC system:

- Secondary throttle control input (TPS B) is used to maintain position control of the throttle and for fuel control
- If TPS B input is unavailable (also a DTC set), the throttle motor is returned to a default (fast-idle) position by the throttle return spring.

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.25 DTC P0123 Throttle Position Sensor High

The ECM utilizes throttle position information to predict airflow into the engine during a transient condition, for idle speed control and for many auxiliary functions. In an electronic throttle control (ETC) system, this sensor is used as the primary feedback mechanism to control airflow through the engine. ETC systems will use at least two throttle position sensors for redundancy.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected in non-ETC system

- Engine idle speed is raised to a programmed value (typically, 1300 RPM)
- Intake manifold pressure is utilized for deceleration and transient fuel control
- Idle speed control may be erratic

Actions taken when fault is detected in an ETC system:

- Secondary throttle control input (TPS B) is used to maintain position control of the throttle and for fuel control
- If TPS B input is unavailable (also a DTC set), the throttle motor is returned to a default (fast-idle) position by the throttle return spring.



---

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.26 DTC P0125 Insufficient Coolant Temperature for Closed-Loop

In order for the fuel system to operate in closed-loop mode, the engine must be warmed up to a minimum temperature. In petrol vehicles, this temperature is often quite warm; however, in a CNG application, normally the engine must only warm up to a temperature that will not cause oxygen sensor damage due to condensation, and catalytic converter activity.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- No ECTS fault detected
- No IATS fault detected
- No MAP fault detected
- No TPS fault detected
- No engine misfire fault detected
- No injector circuit faults detected
- Coolant temperature is below minimum required to enter closed-loop operation mode
- Engine has been running for at least 5 minutes

DTC Logic: Type B

---

- 
- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Observe ECTS reading as engine warms up. Verify ECT value tracks coolant temperature.
- If engine remains cold even after operating for a significant amount of time, verify thermostat operation.
- Verify thermostat operation by checking for warm water flow through the radiator before the desired thermostat opening temperature. If thermostat is not functioning properly, replace thermostat.

### 3.27 DTC P0126 Insufficient Coolant Temperature for Stable Operation

In order for the engine and emission control system to operate properly with good driveability, emissions and fuel consumption, a minimum coolant temperature is required. This DTC will set if this minimum coolant temperature has not been achieved.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- No ECTS fault detected
- No IATS fault detected
- No MAP fault detected
- No TPS fault detected
- No engine misfire fault detected
- No injector circuit faults detected
- Coolant temperature is below 60 degrees C
- Intake air temperature is above -5 degrees C
- Engine has been running for at least 15 minutes

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored

- 
- After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Observe ECTS reading as engine warms up. Verify ECT value tracks coolant temperature.
- If engine remains cold even after operating for a significant amount of time, verify thermostat operation.
- Verify thermostat operation by checking for warm water flow through the radiator before the desired thermostat opening temperature. If thermostat is not functioning properly, replace thermostat.

### 3.28 DTC P0127 Intake Air Temperature Too High

If the air inlet to the engine is too hot, spark knock may occur, along with the associated engine damage. This DTC is used to indicate that the air temperature is too high for the engine. In turbocharged applications, this DTC may indicate incorrect fan operation, a plugged heat exchanger (intercooler), or excessive boost.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- No ECTS fault detected
- No IATS fault detected
- No MAP fault detected
- No TPS fault detected
- Engine air flow above a calibrated value – typically 20 grams per second
- Intake air temperature above a calibrated value – typically 60 degrees C
- Conditions exist for 60 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

---

- 
- Check intake air temperature and boost pressure readings to determine if the problem occurs in high boost conditions.
  - Clean engine cooling radiator and intercooler. Verify proper cooling fan operation.

### 3.29 DTC P0128     Thermostat Performance

For many reasons, the engine should operate at its designed operating temperature. Engine and oil life is prolonged at the proper temperatures. In addition, the fuel pressure regulator can fail prematurely if the coolant is cold for a long period of time. This diagnostic can be used to determine if the engine coolant thermostat is capable of controlling the engine temperature to a reasonable degree (within approximately 10 degrees C).

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- No ECTS fault detected
- No IATS fault detected
- No MAP fault detected
- No TPS fault detected
- No engine misfire fault detected
- No injector circuit faults detected
- Coolant temperature is outside of a 20% window of the modelled engine temperature
- Intake air temperature above -10 degrees C
- Engine coolant temperature above 0 degrees C
- Engine has been running for 5 minutes
- Conditions exist for 15 minutes

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Observe ECTS reading as engine warms up. Verify ECT value tracks coolant temperature.

- 
- Verify thermostat operation by checking for warm water flow through the radiator before the desired thermostat opening temperature. If thermostat is not functioning properly, replace thermostat.

### **3.30 DTC P0129 Barometric Pressure Too Low**

Barometric pressure is used in calculating the air flow into the engine, desired throttle position (in ETC systems), desired idle air control motor position (in IAC systems), and ignition timing. If the calculated or measured barometric pressure is too low, this DTC will set. Air system restriction may set this DTC in some conditions.

Flash code: none

Conditions to run test:

- Barometric pressure estimate is below 60 kPa

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Verify MAP sensor calibration.
- Check for air system restriction.

### **3.31 DTC P0131 Oxygen Sensor 1, Bank 1, Voltage Low**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage is low during a cold soak followed by a key-on cycle. Note that a low voltage fault is also within the operating voltage range of the sensor so this diagnostic is only run during a cold soak where the sensor is not generating a signal at all.

Flash code: none

Conditions to run test:

- At least 600 seconds since the engine was stopped (engine key-off timer)
- Oxygen sensor voltage under 0.05 volts
- Coolant temperature below 45 degrees C

- 
- Condition exists for one second

Actions taken when DTC sets:

- DTC P2195 disabled until the next engine cold-soak

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify oxygen sensor voltage reads between 0.38 and 0.55 volts (stoichiometric sensor), or between 2.8 and 3.2 volts (UEGO sensor). Check wiring if not within range.
- With engine stopped, reconnect sensor. If voltage changes significantly, replace sensor.

### **3.32 DTC P0132 Oxygen Sensor 1, Bank 1, Voltage High**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage is above 1.25 volts.

Flash code: none

Conditions to run test:

- Oxygen sensor voltage above 0.88 volts
- At least 600 seconds since the engine was stopped (engine key-off timer)
- Coolant temperature below 45 degrees C
- Condition exists for one second

OR

- Oxygen sensor voltage above 1.25 volts
- DTC P2231 not present
- Condition exists for one second

Actions taken when DTC sets:

- DTC P2196 disabled so long as the condition exists



---

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

### 3.33 DTC P0133    **Oxygen Sensor 1, Bank 1, Sluggish**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. For proper driveability and emissions performance, the sensor must respond to air-fuel ratio changes quickly. This diagnostic checks the response time of the lambda sensor to a change in the oxygen sensor voltage. A sluggish sensor may result in idle instability and both driveability and emissions performance issues.

Flash code: none

Conditions to run test:

- Oxygen sensor signal amplitude lower than 0.4 volts peak-to-peak
- Condition exists for 35 seconds
- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault
- No ECTS fault
- No IATS fault
- No misfire recorded
- No injector circuit fault
- Higher than 5% fuel storage capacity
- Oxygen sensor warm

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault



- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Disconnect sensor. Verify oxygen sensor voltage reads between 0.38 and 0.55 volts (stoichiometric sensor), or between 2.8 and 3.2 volts (UEGO sensor). Check wiring if not within range.
- With engine stopped, reconnect sensor. If voltage changes significantly, replace sensor.
- On some systems (mostly petrol), excessive rich operation may cause carbon buildup on sensor which can cause this DTC to set. In this case, prolonged high-power operation may clear off carbon residue and restore normal sensor operation.
- Do not attempt to clean the sensor with solvent.

### 3.34 DTC P0134 Oxygen Sensor 1, Bank 1, Inactivity

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage remains between 0.4 and 0.55 volts for an extended period of time.

Flash code: none

Conditions to run test:

- Oxygen sensor voltage between 0.4 and 0.55 volts
- Engine speed above 500 RPM
- Engine load above 10%
- Condition exists for 60 seconds if the ECTS is below 55 degrees C OR
- Condition exists for 150 seconds if the ECTS is above 55 degrees C
- Engine coolant temperature is above freezing (0 degrees C)
- An oxygen sensor heater fault has not been logged this key cycle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

---

- 
- Verify connection of oxygen sensor and heater between ECM and sensor connector.
  - Check for other oxygen sensor faults (including heater faults). Troubleshoot these first.
  - Verify heater power is available at sensor.
  - If sensor does not generate a signal after sufficient warm up time, replace sensor.

### **3.35 DTC P0137    Oxygen Sensor 2, Bank 1 Voltage Low**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. The average air-fuel ratio needs to be maintained within 0.1% for best emissions. The post-catalyst oxygen sensor is used to maintain this air-fuel ratio, and also to diagnose a malfunctioning catalyst. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage is low during a cold soak followed by a key-on cycle. Note that a low voltage fault is also within the operating voltage range of the sensor so this diagnostic is only run during a cold soak where the sensor is not generating a signal at all.

Flash code: none

Conditions to run test:

- At least 600 seconds since the engine was stopped (engine key-off timer)
- Oxygen sensor voltage under 0.05 volts
- Coolant temperature below 45 degrees C
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify oxygen sensor voltage reads between 0.38 and 0.55 volts. Check wiring if not within range.
- With engine stopped, reconnect sensor. If voltage changes significantly, replace sensor.

### **3.36 DTC P0138    Oxygen Sensor 2, Bank 1, Voltage High**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. The

---

---

average air-fuel ratio needs to be maintained within 0.1% for best emissions. The post-catalyst oxygen sensor is used to maintain this air-fuel ratio, and also to diagnose a malfunctioning catalyst. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage is above 1.25 volts.

Flash code: none

Conditions to run test:

- Oxygen sensor voltage above 0.88 volts
- At least 600 seconds since the engine was stopped (engine key-off timer)
- Coolant temperature below 45 degrees C
- Condition exists for one second

OR

- Oxygen sensor voltage above 1.25 volts
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

### **3.37 DTC P0139 Oxygen Sensor 2, Bank 1, Slow response**

The post-catalyst oxygen sensor signal is normally quite slow. During certain driving conditions, the post-catalyst oxygen sensor is expected to rapidly change voltage. During these conditions, if the oxygen sensor voltage does not change rapidly, this DTC will set.

Flash code: none

Conditions to run test:

- Front oxygen sensor signal amplitude greater than 0.6 volts peak-to-peak
- Rear oxygen sensor signal greater than 0.5 volts
- Condition exists for 35 seconds
- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault

- 
- No ECTS fault
  - No IATS fault
  - No misfire recorded
  - No injector circuit fault
  - Greater than 5% fuel remaining in storage
  - Oxygen sensor warm

Then:

- Deceleration fuel cutoff mode enabled
- Rear oxygen sensor takes longer than a programmed amount of time to respond

OR

- Deceleration fuel cutoff mode enabled
- Rear oxygen sensor takes longer than a programmed amount of time to drop from 0.5 volts to 0.2 volts.

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify oxygen sensor voltage reads between 0.38 and 0.55 volts (stoichiometric sensor), or between 2.8 and 3.2 volts (UEGO sensor). Check wiring if not within range.
- With engine stopped, reconnect sensor. If voltage changes significantly, replace sensor.
- On some systems (mostly petrol), excessive rich operation may cause carbon buildup on sensor which can cause this DTC to set. In this case, prolonged high-power operation may clear off carbon residue and restore normal sensor operation.
- Do not attempt to clean the sensor with solvent.

### **3.38 DTC P0140    Oxygen Sensor 2, Bank 1, Inactivity**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. The average air-fuel ratio needs to be maintained within 0.1% for best emissions. The post-catalyst

---

oxygen sensor is used to maintain this air-fuel ratio, and also to diagnose a malfunctioning catalyst. If the oxygen sensor is unable to be read, this diagnostic fault code can indicate the source of the problem. This fault will set if the oxygen sensor voltage remains between 0.4 and 0.55 volts for an extended period of time.

Flash code: none

Conditions to run test:

- Rear oxygen sensor voltage between 0.4 and 0.55 volts
- Front oxygen sensor amplitude greater than 0.6 volts peak-to-peak
- Engine speed above 500 RPM
- Engine load above 10%
- Condition exists for 250 seconds if the ECTS is below 55 degrees C OR
- Condition exists for 150 seconds if the ECTS is above 55 degrees C
- Engine coolant temperature is above freezing (0 degrees C)
- An oxygen sensor heater fault has not been logged this key cycle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Verify connection of oxygen sensor and heater between ECM and sensor connector.
- Check for other oxygen sensor faults (including heater faults). Troubleshoot these first.
- Verify heater power is available at sensor.
- If sensor does not generate a signal after sufficient warm up time, replace sensor.

### **3.39 DTC P0182 Fuel Temperature Sensor Low**

The fuel temperature sensor is used to calculate the density of the fuel, which is used to determine the correct injector fuel pulse width.

Flash code: none

Conditions to run test:

- Fuel temperature signal below 0.1 volts

- 
- Condition exists for one second

Actions taken when fault is detected:

- Fuel temperature uses a calculated substitute value

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V. If not, check wiring for short circuit to ground or adjacent terminals.
- Check resistance of sensor. Verify that it is within specifications.

### **3.40 DTC P0183 Fuel Temperature Sensor High**

The fuel temperature sensor is used to calculate the density of the fuel, which is used to determine the correct injector fuel pulse width.

Flash code: none

Conditions to run test:

- Fuel temperature signal above 4.85 volts
- Condition exists for one second

Actions taken when fault is detected:

- Fuel temperature uses a calculated substitute value

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V.



- 
- Jumper across IATS harness sensor (sensor ground to IATS). Verify temperature sensor voltage reads 0 V. If not, check harness for continuity.
  - Check resistance of sensor. Verify that it is within specifications.

### **3.41 DTC P0192 Fuel Rail Pressure Sensor Low**

The fuel rail pressure sensor is used to determine fuel injector pulse width, to diagnose fuel pressure regulator performance problems, and also to check for fuel system leakage.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Fuel rail pressure sensor level below 0.1 volts
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.42 DTC P0193 Fuel Rail Pressure Sensor High**

The fuel rail pressure sensor is used to determine fuel injector pulse width, to diagnose fuel pressure regulator performance problems, and also to check for fuel system leakage.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Fuel rail pressure sensor level above 4.92 volts



- 
- Condition exists for one second

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### 3.43 DTC P0217 Engine Overheat

Operating the engine with excessive coolant temperature may result in engine damage. This DTC is set when the engine is operated at an excessive coolant temperature.

Flash code: none

Conditions to run test:

- Engine has been running for the calibrated minimum time
- Coolant temperature is above the calibrated minimum temperature
- Condition exists for the calibrated minimum time

DTC Logic: Type C3

- Current DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Verify fan and thermostat operation.
- In towing, racing, or heavy-duty truck applications, check for sufficient radiator cooling capacity.

---

### 3.44 DTC P0219 Engine Over Speed

In order to prevent engine damage, fuelling is disabled above a programmed engine speed. If the engine is operated at a very high speed, engine damage may occur. This may include either catastrophic engine failure (valve/piston contact, tossed connecting rods) to engine life reduction. This DTC is set as an indication of engine abuse.

Flash code: none

Conditions to run test:

- Engine speed greater than the calibrated minimum value
- Condition exists for the calibrated minimum time

DTC Logic: Type C3

- Current DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- In some cases, excessive ignition noise induced into the ignition sensor circuit may cause a false DTC. Normally an ignition suppression capacitor is required between ignition coil supply and the engine block to prevent this.
- Incorrect transmission operation, a stuck open throttle, or driver abuse may set this fault. Check for these conditions.

### 3.45 DTC P0222 Throttle Position Sensor B Low

The ECM utilizes throttle position information to predict airflow into the engine during a transient condition, for idle speed control and for many auxiliary functions. In an electronic throttle control (ETC) system, this sensor is used as the primary feedback mechanism to control airflow through the engine. ETC systems will use at least two throttle position sensors for redundancy.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- 
- Primary throttle control input (TPS A) is still used to maintain position control of the throttle and for fuel control
  - If TPS A input is unavailable (also a DTC set), the throttle motor is returned to a default (fast-idle) position by the throttle return spring.

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.46 DTC P0223 Throttle Position Sensor B High

The ECM utilizes throttle position information to predict airflow into the engine during a transient condition, for idle speed control and for many auxiliary functions. In an electronic throttle control (ETC) system, this sensor is used as the primary feedback mechanism to control airflow through the engine.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- Primary throttle control input (TPS A) is still used to maintain position control of the throttle and for fuel control

- 
- If TPS A input is unavailable (also a DTC set), the throttle motor is returned to a default (fast-idle) position by the throttle return spring.

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.47 DTC P0234 Engine Over Boost Condition

In order to increase engine airflow, a turbocharger with a wastegate control system is commonly used on natural gas engines. If the turbocharger or wastegate do not respond correctly to the ECM control signals, or if mechanical problems exist in the wastegate control system, the engine may receive too much boost pressure, which can result in engine damage. This DTC indicates that this condition exists.

Flash code: none

#### Conditions to run test:

- Boost pressure greater than 10% above setpoint (absolute pressure)
- Condition exists for two seconds

#### Actions taken when fault is detected:

- Turbocharger boost control solenoid is set to minimum boost setting
- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>

#### DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault

- 
- MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Incorrect wastegate plumbing or an inoperative wastegate will typically cause this.
- Incorrect wastegate preload can cause this fault. Verify wastegate opening pressure. The wastegate should be fully open at a pressure below the maximum boost pressure of the engine. Correct the wastegate canister settings. Under most CNG engine use, the wastegate should be open fully at approximately 60 kPa<sub>g</sub> of boost pressure or approximately 8 PSI.
- Verify wastegate operation by disconnecting the wastegate modulator valve, and logging wastegate duty cycle, desired boost pressure, and actual boost pressure. Actual boost pressure should remain below desired boost pressure at full-throttle conditions. If not, the wastegate may not be opening properly, or may be undersized.
- Wastegate solenoid plumbing should be as follows:
  - When solenoid is energized, wastegate canister should be vented to atmosphere, upstream of throttle pressure should be blocked.
  - When solenoid is de-energized, wastegate canister should be connected to upstream of throttle pressure. Atmospheric vent should be blocked.
- Once plumbing is correct and the wastegate operation is verified with the solenoid disconnected, reconnect the solenoid, clear DTC's and re-test while logging wastegate duty cycle, desired boost pressure, and full-throttle conditions.

### 3.48 DTC P0236      **Boost Pressure Sensor Performance**

The boost pressure sensor is used for two functions in the ECM. It is used to control the output of the turbocharger (via the boost control solenoid valve). It also is used to measure the upstream pressure at the throttle valve for airflow estimation. This sensor is only used on turbocharged engines.

This DTC tests the boost pressure sensor by comparing its output with that of the barometric or manifold pressure sensor outputs with the engine stopped.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Engine not running
- Manifold pressure and boost pressure sensor readings are not within 5%
- Condition exists for 1.0 seconds

OR

- 
- No sensor power supply fault recorded
  - Engine running
  - Manifold pressure sensor reads a pressure that is higher than 5% above the boost pressure sensor
  - Condition exists for 5 seconds

Actions taken when fault is detected:

- Long term fuel trim logic is disabled
- Turbocharger boost control solenoid is set to minimum boost setting
- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>
- Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- With engine stationary, verify intake manifold pressure and boost pressure sensor values match. If they do not match, one of the sensors is incorrect (wrong sensor used for this application), or is out of calibration. Replace the sensor that is reading incorrectly. To calculate the correct pressure sensor value at your location, refer to appendix A.

### **3.49 DTC P0237 Boost Pressure Sensor Low**

The boost pressure sensor is used for two functions in the ECM. It is used to control the output of the turbocharger (via the boost control solenoid valve). It also is used to measure the upstream pressure at the throttle valve for airflow estimation. This sensor is only used on turbocharged engines.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Boost pressure signal level below 0.10 volts
- Condition exists for 1.0 seconds

Actions taken when fault is detected:

- Throttle airflow estimation is disabled, transient fuelling will be less accurate
-



- 
- Long term fuel trim logic is disabled
  - Turbocharger boost control solenoid is set to minimum boost setting
  - Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>
  - Engine idle speed is raised to prevent stalling

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.50 DTC P0238     Boost Pressure Sensor High**

The boost pressure sensor is used for two functions in the ECM. It is used to control the output of the turbocharger (via the boost control solenoid valve). It also is used to measure the upstream pressure at the throttle valve for airflow estimation. This sensor is only used on turbocharged engines.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Boost pressure signal level above 4.9 volts
- Condition exists for 1.0 seconds

Actions taken when fault is detected:

- Throttle airflow estimation is disabled, transient fuelling will be less accurate
  - Long term fuel trim logic is disabled
  - Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>
  - Turbocharger boost control solenoid is set to minimum boost setting
  - Engine idle speed is raised to prevent stalling
-



---

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.51 DTC P0245 Turbocharger Wastegate Solenoid Circuit Low**

The control circuit to the turbocharger control solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Actuator power above 10 volts
- Turbocharger wastegate output commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

Actions taken when fault is detected:

- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>
- Turbocharger boost control solenoid is set to minimum boost setting

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the wastegate control solenoid.

### 3.52 DTC P0246 Turbocharger Wastegate Solenoid Circuit High

The control circuit to the turbocharger control solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Actuator power above 10 volts
- Turbocharger wastegate output commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

Actions taken when fault is detected:

- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>
- Turbocharger boost control solenoid is set to minimum boost setting

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the solenoid coil
- Verify wiring between solenoid and ECM

- 
- Verify actuator power (controlled by main actuator power control relay) is available at the wastegate control solenoid.

### 3.53 DTC P0261    **Injector 1 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM

- 
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.54 DTC P0262    Injector 1 Circuit High

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

---

### 3.55 DTC P0263    **Injector 1 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.56 DTC P0264    **Injector 2 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated

---

injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.57 DTC P0265    Injector 2 Circuit High**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

---

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.58 DTC P0266    Injector 2 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

---



- 
- No actuator power supply faults recorded
  - Actuator power relay actuated
  - Actuator power above 10 volts
  - Injector closing time is more than the calibrated value longer or shorter than expected
  - Conditions exist for 60.0 seconds

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.59 DTC P0267     **Injector 3 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

#### Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:

- 
- Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
  - Peak-and-hold driver:
    - Injector commanded on by the ECM
    - driver stage does not achieve required peak current level
  - Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.60 DTC P0268     Injector 3 Circuit High**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:

- 
- Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
  - Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.61 DTC P0269     Injector 3 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored

- 
- After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.62 DTC P0270    Injector 4 Circuit Low

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.63 DTC P0271     Injector 4 Circuit High

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

#### Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

#### DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.64 DTC P0272     **Injector 4 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

#### Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.



- 
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.65 DTC P0273    **Injector 5 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM



- 
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.66 DTC P0274    Injector 5 Circuit High

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

---

### 3.67 DTC P0275    **Injector 5 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.68 DTC P0276    **Injector 6 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated

---

injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.69 DTC P0277    Injector 6 Circuit High**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

---

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.70 DTC P0278    Injector 6 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

---

- 
- No actuator power supply faults recorded
  - Actuator power relay actuated
  - Actuator power above 10 volts
  - Injector closing time is more than 0.5 milliseconds longer or shorter than expected
  - Conditions exist for 60.0 seconds

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.71 DTC P0279     **Injector 7 Circuit Low**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:

- 
- Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
  - Peak-and-hold driver:
    - Injector commanded on by the ECM
    - driver stage does not achieve required peak current level
  - Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.72 DTC P0280    Injector 7 Circuit High**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:



- 
- Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
  - Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### **3.73 DTC P0281     Injector 7 Contribution/Balance**

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.



- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### 3.74 DTC P0282    Injector 8 Circuit Low

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Controllers designed for peak-and-hold injectors monitor current flow to set this diagnostic, controllers designed for saturated injectors monitor pin voltage to set this DTC. If using a saturated injector on a peak-and-hold driver, in most cases, this DTC must be disabled and this circuit cannot be diagnosed.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded off by the ECM
  - Driver IC records low voltage fault (short to ground or open load)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage does not achieve required peak current level
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault

- 
- MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.75 DTC P0283 Injector 8 Circuit High

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the fuel injector, or that the fuel injector is faulty. This may set if the fuel injector control wire has a short circuit to ground or an open circuit or blown fuse.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Saturated injector driver:
  - Injector commanded on by the ECM
  - Driver IC records high voltage fault (short to power)
- Peak-and-hold driver:
  - Injector commanded on by the ECM
  - driver stage requires less than 12% duty cycle to maintain peak current level
  - At least six PWM cycles have been monitored
- Conditions exist for 2.0 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault

- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Verify resistance of the injector coil
- Verify wiring between injector and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the injector. ECM damage may occur if another power source is used to operate the fuel injectors on a peak-and-hold injection system.

### 3.76 DTC P0284    Injector 8 Contribution/Balance

This diagnostic is used to monitor injector closing delay time. On large natural gas injectors, this gives a good indication of the health of an injector. Normally as the injector ages (accumulates contaminants, wears out), the closing time increases. Once the injector is out of tolerance, air-fuel errors will exist and the injector will need to be replaced. Not all injectors provide an indication of valve closure to the ECM, on these injectors this DTC should be disabled.

Flash code: none

#### Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Actuator power above 10 volts
- Injector closing time is more than 0.5 milliseconds longer or shorter than expected
- Conditions exist for 60.0 seconds

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Only some large natural gas injectors are able to be diagnosed using this method.
- Usually this indicates an injector with marginal performance. Compare the measured closing times of this injector with the others. If the closing time is significantly different than other injectors, replace the injector and verify the closing time is close to nominal.

- 
- Contamination of the injector may cause this issue. Contact the injector supplier for cleaning recommendations.

### **3.77 DTC P0297    Vehicle Over Speed**

In order to prevent vehicle and personal damage, fuelling is disabled above a programmed vehicle speed. If the vehicle is operated at a very high speed, damage may occur to the vehicle, occupants, bystanders, and payload. This DTC is set as an indication of vehicle abuse.

Flash code: none

Conditions to run test:

- Vehicle speed greater than 3 km/h over the programmed vehicle speed limit.
- Condition exists for ten seconds

DTC Logic: Type C3

- Current DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Electrical noise or a poor connection may result in a high vehicle speed sensor reading. Verify vehicle speed sensor operates correctly.
- Most common cause of this DTC is excessive vehicle speed (vehicle abuse).
- Ensure vehicle speed limiter hardware has not been tampered with.

### **3.78 DTC P0300    Random Misfire**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set. If several cylinders appear to be misfiring, or if an identification of which cylinder is missing cannot be made, this DTC will set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C

- 
- Above 5% fuel storage quantity
  - Engine not in fuel disable mode (deceleration or speed limiting)
  - Throttle not moved more than 4% per engine revolution
  - Spark timing not changing more than 3 crank degrees per revolution
  - Cylinder acceleration not as expected
  - Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
  - Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B

- In the case of a catalyst-damaging misfire, the Malfunction Indicator Lamp will flash at 1 Hz.
- This will appear on a scan tool as a pending DTC until the misfire diagnostic logic determines that a type B DTC is required.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- Normally, a multiple cylinder misfire indicates a fuel delivery problem that affects the entire engine.
- Check system fuel pressure and pressure regulator performance.
- This DTC may set if the engine speed signal has excessive variance.
- A rough road condition may set this DTC incorrectly.
- Improper balance of drivetrain components may set this DTC incorrectly.
- Check the engine misfire counters while operating the vehicle to see if one or two cylinders are contributing many more misfires but the ECM algorithm is not able to identify them with the degree of certainty required. If so, troubleshoot the highest-counting cylinders first.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.

- 
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.79 DTC P0301 Misfire, Cylinder 1**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints



- 
- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
  - On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
  - This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
  - If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
  - Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
  - Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
  - Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.80 DTC P0302 Misfire, Cylinder 2**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution



- 
- Cylinder acceleration not as expected
  - Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
  - Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

---

### 3.81 DTC P0303 Misfire, Cylinder 3

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition

---

secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.

- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.82 DTC P0304 Misfire, Cylinder 4**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR

- 
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.83 DTC P0305      Misfire, Cylinder 5**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted.

---

If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.

- 
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
  - If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
  - Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
  - Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
  - Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.84 DTC P0306      Misfire, Cylinder 6**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y



- 
- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault
  - MIL will flash while catalyst-damaging misfire has been detected

#### Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### 3.85 DTC P0307 Misfire, Cylinder 7

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults



- 
- No TPS fault
  - No ECTS fault
  - ECTS between 10 degrees C and 110 degrees C
  - Above 5% fuel storage quantity
  - Engine not in fuel disable mode (deceleration or speed limiting)
  - Throttle not moved more than 4% per engine revolution
  - Spark timing not changing more than 3 crank degrees per revolution
  - Cylinder acceleration not as expected
  - Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
  - Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.

- 
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
  - Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
  - Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.86 DTC P0308      Misfire, Cylinder 8**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Above 5% fuel storage quantity
- Engine not in fuel disable mode (deceleration or speed limiting)
- Throttle not moved more than 4% per engine revolution
- Spark timing not changing more than 3 crank degrees per revolution
- Cylinder acceleration not as expected
- Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
- Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault

- 
- DTC will clear after forty consecutive normal trips without a fault
  - MIL will flash while catalyst-damaging misfire has been detected

#### Troubleshooting Hints

- On central injection engines, a single-cylinder misfire is usually due to poor ignition. Note that the ignition circuit DTC is unable to diagnose anything other than an open circuit secondary. If any spark occurs – down the insulator of a cracked spark plug, or a break in the ignition secondary insulation – the ignition DTC will not set. Verify proper ignition performance and carefully inspect the ignition system.
- On multipoint injection engines, a single-cylinder misfire can be caused by poor ignition or fuel delivery. Verify correct fuel delivery on multipoint engines.
- This fault may be caused by engine damage. This can usually be verified by checking engine compression pressures.
- If the engine misfires at idle, a leaking or stuck-open injector is a common cause. Note that fuel trim values may not be correct as a misfiring engine will cause erratic and erroneous oxygen sensor readings.
- Turbocharged engines require high ignition voltage, so a wide spark plug gap (caused by incorrect adjustment or through spark plug wear) may result in an engine misfire at high engine loads.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.87 DTC P0313 Misfire Detected with Low Fuel**

The ECM utilizes engine crankshaft speed and position information to determine if an engine cylinder is not properly utilizing its fuel and air. During each power stroke, the crankshaft accelerates just after the fuel has been burned. If this acceleration is not detected, an engine misfire is counted. If sufficient misfires occur to set a DTC, the cylinder in question is identified and an appropriate DTC is set. If the fuel storage system has a low quantity, this DTC is set to indicate that the misfire was likely due to operator error.

Flash code: none

Conditions to run test:

- No MAP sensor faults
- No TPS fault
- No ECTS fault
- ECTS between 10 degrees C and 110 degrees C
- Fuel storage pressure lower than 1.25 MPa

- 
- Engine not in fuel disable mode (deceleration or speed limiting)
  - Throttle not moved more than 4% per engine revolution
  - Spark timing not changing more than 3 crank degrees per revolution
  - Cylinder acceleration not as expected
  - Misfire counts in 200 engine revolutions exceed a catalyst damaging threshold OR
  - Misfire counts in 1000 engine revolutions exceed an emissions degrading threshold

Actions taken when fault is detected:

- While a catalyst-damaging misfire is present, the MIL will flash at 1 Hz.

DTC Logic: Type B / Y

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault
- MIL will flash while catalyst-damaging misfire has been detected

Troubleshooting Hints

- Normally, on a CNG engine, low fuel pressure only causes a lean shift (and increased emissions) and no engine misfire. Some engines will misfire when too lean, and this DTC will set.
- Ensure the operator knows to not operate the vehicle at these fuel levels.
- Poorly constructed or designed engine speed sensor masks may cause false a misfire DTC.
- Poor or uneven combustion due to excessive valve overlap, excessive EGR, or a camshaft designed for auto sports may set a misfire DTC even if no misfire occurs.

### **3.88 DTC P0327      Knock Sensor 1 Low**

Engine knock is measured using accelerometers and a frequency-selective level measurement. During normal engine operation, the sensor should generate a minimal but measurable output signal. If this minimum signal is not detected, the sensor is likely defective or disconnected.

Flash code: none

Conditions to run test:

- Knock input level lower than 5%
- Engine is running

- 
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Guide

- ***FUTURE SOFTWARE FEATURE*** To test the knock sensor, enter knock sensor test mode with the engine stationary. Gently tap the engine block with a hammer and monitor the knock sensor channel output.
- With ECM firmware without the knock sensor test mode, idle the engine and repeatedly tap the engine block with a hammer, while monitoring the knock sensor output using a scan tool. Occasionally, the knock sensor output should increase. If it does not, check sensor wiring, and if no problems are found, replace the sensor.
- If the engine is equipped with two knock sensors, temporarily swap the sensor wires to determine if it is a wiring, harness, or ECM problem.

### 3.89 DTC P0328 Knock Sensor 1 High

Engine knock is measured using accelerometers and a frequency-selective level measurement. Normally this signal should not be full-scale. This may indicate a wiring problem with the sensor, a defective sensor, or an engine that is about to come apart.

Flash code: none

Conditions to run test:

- Knock input level higher than 95%
- Engine is running
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault
-

---

## Troubleshooting Hints

- Idle the engine. If the engine sounds like it is about to come apart, repair the engine first. The knock sensor system detects engine noise and assumes that excessive engine noise is preignition (knock). If the excessive engine noise is the engine beating itself apart, the ECM will consider this to be engine knock.
- Disconnect the knock sensor, with the engine idling. The knock level should be very low (below 0.05). If it is high, check the sensor wiring for proper shielding and grounding. If no problems are found, replace the ECM.
- Connect the knock sensor, with the engine idling. The knock level should go up slightly, but still be very low. The actual value is engine dependant.
- This DTC may set in the case of prolonged, uncontrolled knocking. Verify that fuel quality is sufficient for the application.
- This DTC may set in the case of certain engine damage such as a connecting rod or crankshaft bearing failure. Repair the engine if this occurs.
- Incorrect valve clearance adjustment may generate enough noise to cause an incorrect knock indication.
- If the engine is equipped with two knock sensors, a comparison of the two outputs may be useful to determine if it is an engine, sensor, wiring, or ECM fault.

### 3.90 DTC P0332 Knock Sensor 2 Low

Engine knock is measured using accelerometers and a frequency-selective level measurement. During normal engine operation, the sensor should generate a minimal but measurable output signal. If this minimum signal is not detected, the sensor is likely defective or disconnected.

Flash code: none

Conditions to run test:

- Knock input level lower than 5%
- Engine is running
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault



---

## Troubleshooting Guide

- ***FUTURE SOFTWARE FEATURE*** To test the knock sensor, enter knock sensor test mode with the engine stationary. Gently tap the engine block with a hammer and monitor the knock sensor channel output.
- With ECM firmware without the knock sensor test mode, idle the engine and repeatedly tap the engine block with a hammer, while monitoring the knock sensor output using a scan tool. Occasionally, the knock sensor output should increase. If it does not, check sensor wiring, and if no problems are found, replace the sensor.
- If the engine is equipped with two knock sensors, temporarily swap the sensor wires to determine if it is a wiring, harness, or ECM problem.

### 3.91 DTC P0333 Knock Sensor 2 High

Engine knock is measured using accelerometers and a frequency-selective level measurement. Normally this signal should not be full-scale. This may indicate a wiring problem with the sensor, a defective sensor, or an engine that is about to come apart.

Flash code: none

Conditions to run test:

- Knock input level higher than 95%
- Engine is running
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Idle the engine. If the engine sounds like it is about to come apart, repair the engine first. The knock sensor system detects engine noise and assumes that excessive engine noise is preignition (knock). If the excessive engine noise is the engine beating itself apart, the ECM will consider this to be engine knock.
- Disconnect the knock sensor, with the engine idling. The knock level should be very low (below 0.05). If it is high, check the sensor wiring for proper shielding and grounding. If no problems are found, replace the ECM.



- 
- Connect the knock sensor, with the engine idling. The knock level should go up slightly, but still be very low. The actual value is engine dependant.
  - This DTC may set in the case of prolonged, uncontrolled knocking. Verify that fuel quality is sufficient for the application.
  - This DTC may set in the case of certain engine damage such as a connecting rod or crankshaft bearing failure. Repair the engine if this occurs.
  - Incorrect valve clearance adjustment may generate enough noise to cause an incorrect knock indication.
  - If the engine is equipped with two knock sensors, a comparison of the two outputs may be useful to determine if it is an engine, sensor, wiring, or ECM fault.

### **3.92 DTC P0335      Crankshaft Position Sensor Circuit Fault**

Engine position is measured based on a signal received from the crankshaft position sensor. If no CKP signal is available, the engine will not run. The high-resolution signal is also used for engine misfire monitoring.

Flash code: none

Conditions to run test:

- At least five CMP transitions
- No engine speed signal received

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the wiring of this signal for open or short circuits.
- Note that hall-effect and magnetostrictive sensors require power. Ensure power is present for these sensor types.
- These active sensors also are supplied with +5 V from the ECM on the signal line. With the sensor disconnected, check for voltage between sensor ground and the CKP or CMP signal. Variable reluctance sensors do not have this voltage applied.
- Check the sensor for mechanical damage.
- For variable reluctance sensor, check the sensor for proper resistance.

- 
- A variable reluctance sensor may be checked by connecting a voltmeter set to measure AC voltage to the sensor and cranking the engine. The sensor will generate its own voltage.

### **3.93 DTC P0340 Camshaft Position Sensor Fault**

Along with the CKP sensor, the CMP sensor is used to synchronize the ignition and injection to the engine position. Unlike the CKP sensor, however, the CMP sensor is not required to run the engine. A lengthened start time is likely with a faulted CMP sensor.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- No CMP signal is received within ten crankshaft revolutions

Actions taken when fault is detected:

- Random engine synchronization will be used, using only the CKP signal for position reference
- If the engine does not start after ten crankshaft revolutions, the simulated CMP phasing will be inverted at a frequency of 1 Hz until the engine starts
- Once the engine starts, it can run indefinitely on the CKP sensor alone.

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the wiring of this signal for open or short circuits.
- Note that hall-effect and magnetostrictive sensors require power. Ensure power is present for these sensor types.
- These active sensors also are supplied with +5 V from the ECM on the signal line. With the sensor disconnected, check for voltage between sensor ground and the CKP or CMP signal. Variable reluctance sensors do not have this voltage applied.
- Check the sensor for mechanical damage.
- For variable reluctance sensor, check the sensor for proper resistance.
- A variable reluctance sensor may be checked by connecting a voltmeter set to AC volts to the sensor and cranking the engine. The sensor will generate its own voltage.

---

### 3.94 DTC P0420 Catalyst System Low Efficiency

The ECM monitors the oxygen storage capability of the catalyst to infer the conversion efficiency of the catalyst. Oxygen storage capability is inferred by monitoring the amplitude of the post-catalyst oxygen sensor. When the oxygen storage capability of the catalyst has dropped to a programmed threshold, this DTC will set.

Flash code: none

Conditions to run test:

- Engine operating in closed loop mode
- Post-catalyst fuel trim enabled
- Rear oxygen sensor signal amplitude is above a programmed limit
- Engine operating in a steady-state mode
- Condition met for 20 seconds
- Test fails a programmed number of times

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Check catalyst for mechanical damage
- Check emissions using a portable emissions analyzer for presence of catalyst activity.

### 3.95 DTC P0462 Fuel Quantity Sensor Low

The fuel quantity sensor is used primarily to provide an output to the instrument cluster. It also plays a role in allowing long-term fuel trims to operate.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Fuel quantity signal level below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected:

---

- 
- Long term fuel trim logic is disabled

DTC Logic: Type C2.

- On trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive quick trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.96 DTC P0463 Fuel Quantity Sensor High**

The fuel quantity sensor is used primarily to provide an output to the instrument cluster. It also plays a role in allowing long-term fuel trims to operate.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Fuel quantity signal level above 4.92 volts
- Condition exists for one second

Actions taken when fault is detected:

- Long term fuel trim logic is disabled

DTC Logic: Type C2.

- On trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive normal trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

---

- 
- Check for sensor power supply fault. Troubleshoot first.
  - Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
  - Check for +5 V sensor power and sensor ground for continuity and/or voltage.
  - Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### 3.97 DTC P0502    Vehicle Speed Sensor Low

The vehicle speed sensor is primarily used in idle speed control to determine if the vehicle is idling or coasting down. It also is used for MIL records, fuel consumption, odometer, and vehicle speed limiting.

Flash code: none

Conditions to run test:

- Vehicle speed indicates below 1.5 km/h
- Manifold pressure indicates greater than 50 kPa<sub>a</sub>
- Engine speed above 2000 RPM
- Throttle position is above 5%
- No MAP sensor faults detected
- No TPS faults detected
- No ECTS fault detected
- No engine misfire fault detected
- No injector circuit fault detected
- No sensor power fault detected
- The above conditions are present for 25 seconds

Actions taken when fault is detected:

- Backup vehicle speed limiting mode via engine speed limiting is enabled

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

---

## Troubleshooting Hints

- Check the wiring of this signal for open or short circuits.
- Note that hall-effect sensors require power. Ensure power is present for these sensor types.
- These active sensors also are supplied with +5 V from the ECM on the signal line. With the sensor disconnected, check for voltage between sensor ground and the vehicle speed signal. Variable reluctance sensors do not have this voltage applied.
- To test a hall effect vehicle speed sensor signal, while displaying vehicle speed on a scan tool, rapidly ground and open a jumper wire between the vehicle speed signal and ground. The vehicle speed sensor reading should indicate an erratic vehicle speed. If it does not, check the wiring.
- Check the sensor for mechanical damage.
- For variable reluctance sensor, check the sensor for proper resistance.

### 3.98 DTC P0503 Vehicle Speed Sensor High or Erratic

The vehicle speed sensor is primarily used in idle speed control to determine if the vehicle is idling or coasting down. It also is used for MIL records, fuel consumption, odometer, and vehicle speed limiting.

Flash code: none

Conditions to run test:

- Vehicle speed indicates above 250 km/h OR
- Change in vehicle speed exceeds 20 km/h per second
- Conditions exist for 5 seconds.

Actions taken when fault is detected:

- Backup vehicle speed limiting mode via engine speed limiting is enabled

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## Troubleshooting Hints

- Check the wiring of this signal for open or short circuits.
  - Note that hall-effect sensors require power. Ensure power is present for these sensor types.
-



- 
- These active sensors also are supplied with +5 V from the ECM on the signal line. With the sensor disconnected, check for voltage between sensor ground and the vehicle speed signal. Variable reluctance sensors do not have this voltage applied.
  - To test a hall effect vehicle speed sensor signal, while displaying vehicle speed on a scan tool, rapidly ground and open a jumper wire between the vehicle speed signal and ground. The vehicle speed sensor reading should indicate an erratic vehicle speed. If it does not, check the wiring.
  - Check the sensor for mechanical damage.
  - For variable reluctance sensor, check the sensor for proper resistance.
  - In some cases, excessive wheel slippage and erratic traction may cause this DTC to set.

### **3.99 DTC P0506 Idle Control System RPM Too Low**

A stepper motor IAC or an electronic throttle controls engine idle speed. If the IAC is not able to control idle speed, this DTC will set. It may be caused by poor fuel control or a sticking IAC.

Flash code: 38

Conditions to run test:

- Engine idle speed at least 100 RPM below nominal idle speed
- Vehicle not moving
- TPS at idle (rest) position
- Engine speed not cycling rapidly (hunting)
- Coolant temperature above 42 degrees C
- Intake air temperature above -11 degrees C
- Manifold pressure below 60 kPa<sub>a</sub>
- No IAC circuit fault detected
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No engine misfire detected
- No injector circuit fault detected
- No sensor power fault detected
- No IAC circuit fault detected

---

## DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

## Troubleshooting Hints

- This fault may be caused by an inoperative or plugged IAC.
- Low idle speed may also be caused by fuel, ignition, and engine misfire problems.
- A disconnected or faulty manifold pressure signal may cause this fault.
- In systems with vacuum hoses attaching the manifold pressure sensor signal to the intake manifold, verify that the hose is in good condition and connected correctly.

### 3.100 DTC P0507 Idle Control System RPM Too High

A stepper motor IAC or an electronic throttle controls engine idle speed. If the IAC is not able to control idle speed, this DTC will set. This DTC may be caused by an air leak, a sticking throttle, a sticking throttle cable or a sticking IAC.

Flash code: 38

#### Conditions to run test:

- Engine idle speed at least 100 RPM below nominal idle speed
- Vehicle not moving
- TPS at idle (rest) position
- Engine speed not cycling rapidly (hunting)
- Coolant temperature above 42 degrees C
- Intake air temperature above -11 degrees C
- Manifold pressure below 60 kPa<sub>a</sub>
- No IAC circuit fault detected
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No engine misfire detected

- 
- No injector circuit fault detected
  - No sensor power fault detected
  - No IAC circuit fault detected

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This fault may set in the case of a faulty crankcase ventilation valve, power brake booster, or vacuum hose.
- On a mechanically controlled throttle system, this fault may set in the case of a sticking-open throttle. Physically check the throttle position to ensure that it closes correctly against its stop. Check the linkages, cables, and springs for binding.
- Check the IAC for proper operation.

### 3.101 DTC P0508 Idle Air Control Circuit Low

Non electronic throttle ECM's are designed to control idle speed using a four-wire stepper motor. The driver circuit can detect a fault in the wiring and will set DTC P0508, P0509, or possibly both, depending on the circuit fault. Some ECM's are not capable of diagnosing idle air control valve circuit faults. In these ECM's, this test will be disabled automatically.

Flash code: 38

#### Conditions to run test:

- Battery voltage is between 9 and 18 volts
- Engine running for at least 5 seconds
- IAC motor performs 32 steps with a fault recorded by the output driver IC

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault
-

---

## Troubleshooting Hints

- In almost all cases, a wiring problem is the cause of this fault.

### 3.102 DTC P0509 Idle Speed Control Circuit High

Non electronic throttle ECM's are designed to control idle speed using a four-wire stepper motor. The driver circuit can detect a fault in the wiring and will set DTC P0508, P0509, or possibly both, depending on the circuit fault. Some ECM's are not capable of diagnosing idle air control valve circuit faults. In these ECM's, this test will be disabled automatically.

Flash code: 38

Conditions to run test:

- Battery voltage is between 9 and 18 volts
- Engine running for at least 5 seconds
- IAC motor performs 32 steps with a fault recorded by the output driver IC

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- In almost all cases, a wiring problem is the cause of this fault.

### 3.103 DTC P0522 Engine Oil Pressure Sensor Low

The engine oil sensor is used primarily to provide an output to the instrument cluster and as an input for the engine protection system.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Oil pressure sensor level below 0.1 volts
- Condition exists for one second

DTC Logic: Type C2.

- 
- On trip with first fault, pending DTC stored
  - No freeze-frame data will be stored
  - MIL will illuminate after two consecutive normal trips with a fault
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.104 DTC P0523 Engine Oil Pressure Sensor High**

The engine oil sensor is used primarily to provide an output to the instrument cluster and as an input for the engine protection system.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Oil pressure sensor level above 4.92 volts
- Condition exists for one second

DTC Logic: Type C2.

- On trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive normal trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.

- 
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.

### **3.105 DTC P0524 Engine Oil Pressure Low**

This DTC indicates the engine's oil pressure is low and engine damage may have occurred. In some calibrations, the engine is forced to shut down.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Oil pressure below an RPM-dependant value
- Condition exists for an RPM-dependant time

DTC Logic: Type C3

- Current DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Verify oil pressure using the engine manufacturer's procedure and test limits.
- Engine damage may have occurred if the engine was operated with a low oil pressure for an extended period of time.

### **3.106 DTC P0530 Air Conditioning Pressure Sensor Circuit Error**

This DTC indicates that the air conditioning pressure sensor does not appear to reflect the expected pressure in the air conditioning system. In the case of an A/C pressure switch, this indicates that the expected state of the pressure switch is incorrect. A/C operation will usually be blocked while this DTC is set.

Flash code: none

Conditions to run test:

- Intake air temperature below 40 degrees C
- Engine coolant temperature below 40 degrees C
- Engine has not been running
- Air conditioning pressure above programmed limit
- Air conditioning clutch disengaged
- Condition met for 30 seconds



---

DTC Logic: Type C2

- Not emissions related
- On quick trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive quick trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Verify wiring to A/C pressure sensor/switch
- Check A/C pressure using a HVAC gauge manifold.

### 3.107 DTC P0534 Air Conditioning Refrigerant Loss

This DTC indicates that the air conditioning pressure sensor appears to indicate that the system pressure of the A/C system is too low. In the case of an A/C pressure switch, this indicates that the expected state of the pressure switch is incorrect.

Flash code: none

Conditions to run test:

- Intake air temperature above 12 degrees C
- Engine coolant temperature above 12 degrees C
- Seasonal average temperature above 12 degrees C
- Engine has not been running prior to start of test
- Air conditioning pressure below programmed limit
- Condition met for 30 seconds
- Temperature conditions remain correct for 5 minutes

DTC Logic: Type C2

- Not emissions related
- On quick trip with first fault, pending DTC stored
- No freeze-frame data will be stored
- MIL will illuminate after two consecutive quick trips with a fault
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

---

## Troubleshooting Hints

- Very cold ambient or evaporator core temperatures may set this DTC in some conditions.
- Check the evaporator core for icing conditions and cold ambient air temperature conditions.
- Verify wiring to A/C pressure sensor/switch.
- In the case of an A/C pressure switch, it is likely that this DTC is detecting a switch or wiring malfunction, or an extreme temperature or freezing condition.
- In the case of an A/C pressure sensor, it is more likely that this DTC is indicating a pressure loss.
- Check A/C pressure using a HVAC gauge manifold.

### 3.108 DTC P0545 Exhaust Temperature Sensor Low

The exhaust temperature sensor may be used to either sense the exhaust gas temperature leaving the engine or the temperature of the exhaust after the catalytic converter. In both cases, it is used primarily as an engine protection input for engine derating. A short to ground on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- Exhaust temperature signal below 0.1 volts
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Disconnect sensor. Verify temperature sensor voltage reads 5 V. If not, check wiring for short circuit to ground or adjacent terminals.
- Check resistance of sensor. Verify that it is within specifications.

### 3.109 DTC P0546 Exhaust Temperature Sensor High

The exhaust temperature sensor may be used to either sense the exhaust gas temperature leaving the engine or the temperature of the exhaust after the catalytic converter. In both cases, it is used

---

---

primarily as an engine protection input for engine derating. An open circuit or a short circuit to power on this sensor signal will generate this fault.

Flash code: none

Conditions to run test:

- Exhaust temperature signal above 4.85 volts
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

### **3.110 DTC P0561 System Voltage Unstable**

Ignition power voltage is monitored for ignition dwell control, ECM power-up and power-down sequencing, and voltage diagnostics. Fuel injection controllers are dependant on a stable system voltage. This fault indicates that the charging system or battery is unable to maintain a nominal system voltage.

Flash code: none

Conditions to run test:

- Engine running above 750 RPM
- Key switched power signal varying excessively
- Condition exists for 20 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- The battery and alternator should be checked for proper operation.

---

### 3.111 DTC P0562 System Voltage Low

Ignition power voltage is monitored for ignition dwell control, ECM power-up and power-down sequencing, and voltage diagnostics. Fuel injection controllers are dependant on a stable system voltage. This fault indicates that the charging system or battery is unable to maintain a nominal system voltage.

Flash code: none

Conditions to run test:

- Engine running above 750 RPM
- Key switched power signal below 9 volts
- Condition exists for 20 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- The battery and alternator should be checked for proper operation.

### 3.112 DTC P0563 System Voltage High

Ignition power voltage is monitored for ignition dwell control, ECM power-up and power-down sequencing, and voltage diagnostics. Fuel injection controllers are dependant on a stable system voltage. This fault indicates that the charging system, wiring or battery is unable to maintain a nominal system voltage. High voltage may damage or reduce the life of ECM's and peripheral components. This DTC must be rectified immediately.

Flash code: none

Conditions to run test:

- Key switched power signal above 18 volts (12 volt systems) OR
- Key switched power signal above 32 volts (24 volt systems)
- Condition exists for 0.5 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored

- 
- After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- The battery and alternator should be checked for proper operation.

### 3.113 DTC P0603 Keep-Alive Memory Fault

Adaptive learn values are kept in EEPROM, and are saved at each key-off cycle. If there is no saved EEPROM data, this fault code will set. This DTC will not cause a MIL to illuminate normally because trip information will not be available on power-up if this DTC is present. To troubleshoot this fault code, erase the fault code, turn off the keyed power for at least 2-3 minutes or until the off time is 1 minute greater than that calibrated in the P0093 / P0094 Leak Test duration, and see if it reappears when the key is turned back on. The time delay is needed to ensure that the ECM uses the stored information from EEPROM and not the same data located in temporary memory (RAM).

Flash code: none

Conditions to run test:

- No EEPROM data is present on an ECM power-up cycle
- Full ECM power cycle and memory clear is needed to run this test (12 to 15 minutes)

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure battery power is not removed from the ECM. The ECM requires continuous battery power applied to it to maintain its non-volatile memory.

### 3.114 DTC P0604 RAM Fault

The ECM uses RAM (memory) for storage of calibration information and intermediate calculation values used to operate the engine. If the memory system indicates the inability to retrieve memory contents reliably, this fault will set. In some cases, the ECM will not run and may set a DTC P0605 fault instead.

Flash code: none

---

Conditions to run test:

- No EEPROM data is present on an ECM power-up cycle
- Full ECM power cycle and memory clear is needed to run this test (12 to 15 minutes)

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure battery power is not removed from the ECM. The ECM requires continuous battery power applied to it to maintain its non-volatile memory.

### **3.115 DTC P0605 Flash/ROM Fault**

The ECM firmware is stored in flash memory. On power-up a checksum is performed on the flash memory array. If the checksum is incorrect, the ECM will not run and this DTC will be reported. In addition, if the firmware file is corrupt or inoperative, after several attempts to restart the program, the ECM will enter a firmware update mode and set this DTC.

Flash code: none

Conditions to run test:

- ECM Power-up cycle

DTC Logic: Special

- This fault code is not stored in EEPROM. It is reported when the ECM is in a mode to accept firmware.

### **3.116 DTC P0606 ECM Fault**

This DTC is set if it has not passed the ECM functional check during manufacturing, or if the boot ROM is corrupt.

Flash code: none

Conditions to run test:

- ECM Power-up cycle

DTC Logic: Special

- This fault code is not stored in EEPROM.



---

### 3.117 DTC P0615 Starter Control Relay Circuit

The control circuit to the starter relay is tested for continuity. A faulty relay or wiring problems will typically cause this DTC to set. Auto-start and some crank-inhibit systems can detect short to ground, open circuit, and short to power. Many crank-inhibit systems can only detect a short to power.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Starter relay commanded on
- Output driver IC records circuit fault (short to ground, open load, or short to battery)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### 3.118 DTC P0622 Alternator Field Current Monitor Fault

The alternator field current monitor signal is used to determine the load placed on the engine from the alternator. The idle speed control motor (or throttle, in ETC systems) is opened in response to increasing load.

Flash code: none

Conditions to run test:

- No alternator field monitor signal is received within ten seconds.
- The engine is running.

Actions taken when fault is detected:

- Alternator field monitor will not be used for idle speed control.

DTC Logic: Type B

- On trip with first fault, pending DTC stored

- 
- On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check the wiring of this signal for open or short circuits.
- Check the alternator and battery for proper operation.
- A discharged battery may cause this fault if the alternator operates at full field for an extended period of time.

### **3.119 DTC P0636 Power Steering Control Relay Circuit Open**

The control circuit to the power steering control relay is tested for continuity. A faulty relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Power steering control relay commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### **3.120 DTC P0637 Power Steering Control Relay Circuit Shorted**

The control circuit to the power steering control relay is tested for continuity. A faulty relay or wiring problems will typically cause this DTC to set.

Flash code:

---

---

Conditions to run test:

- Key power voltage greater than 6 volts
- Power steering control relay commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### **3.121 DTC P0638 Throttle Control Performance**

In electronic throttle systems, the ECM monitors the desired and commanded position of the throttle blade to determine if the throttle control system is able to control engine airflow. A throttle motor and gearbox model is used to disable this test during rapid throttle transitions where the throttle position trails the commanded position.

Flash code: none

Conditions to run test:

- Engine running
- Throttle not in limp-home position mode (at least one TPS is valid)
- Modelled throttle position within 1% of commanded throttle position.
- Measured and commanded throttle position difference greater than 7%
- Condition exists for 0.125 seconds

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- With the ECM powered on and the key turned on, verify free motion of the throttle plate by depressing the accelerator pedal slowly then releasing it slowly. The throttle plate will follow the accelerator pedal position. If the throttle makes strange noises, or sticks, the throttle body assembly should be checked for binding, foreign material, or debris.
- Ensure that there are no overhanging gaskets, which may occasionally catch the throttle plate.
- The throttle blade and some of the machined features in the throttle body are extremely sharp. Use caution if checking out the motion of the throttle manually. To avoid serious injury, ensure the throttle connector is disconnected before doing any manual checks.
- The throttle plate may move without notice, even with the ignition key off. Do not place fingers or other body parts in the throttle body at any time, unless the throttle body is electrically disconnected.

### 3.122 DTC P0642     **Sensor Reference Voltage A Low**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply below 4.6 volts
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Wiring faults or defective sensors may cause this fault.
- Some versions of control modules (first production A31) cannot measure the analogue voltage level. Troubleshoot these modules using a voltmeter.
- To isolate a defective sensor, disconnect all sensors powered from the Sensor Reference Voltage A power supply, while monitoring the sensor power supply either on a scan tool or

---

with a voltmeter. When the defective sensor is plugged back in, the voltage will fall. Replace that sensor.

### **3.123 DTC P0643    Sensor Reference Voltage A High**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply above 5.4 volts
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Normally this fault will set in the case of a wiring fault. Check for a short circuit to battery voltage, or an open circuit in a sensor ground wire.

### **3.124 DTC P0646    A/C Control Relay Circuit Open**

The control circuit to the A/C clutch relay is tested for continuity. A faulty A/C clutch control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- A/C control relay commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

---

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### 3.125 DTC P0647 A/C Control Relay Circuit Shorted

The control circuit to the A/C clutch relay is tested for continuity. A faulty A/C clutch control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- A/C control relay commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### 3.126 DTC P0650 Malfunction Indicator Lamp Circuit Fault

The ECM uses the MIL lamp to call attention to emissions or driveability related faults. If the MIL has a circuit fault this fault is set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- MIL output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type B3.

---



- 
- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - MIL is not activated for this fault.
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### 3.127 DTC P0652     **Sensor Reference Voltage B Low**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply below 4.6 volts
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Wiring faults or defective sensors may cause this fault.
- Some versions of control modules (first production A31) cannot measure the analogue voltage level. Troubleshoot these modules using a voltmeter.
- To isolate a defective sensor, disconnect all sensors powered from the Sensor Reference Voltage B power supply, while monitoring the sensor power supply either on a scan tool or with a voltmeter. When the defective sensor is plugged back in, the voltage will fall. Replace that sensor.

---

### 3.128 DTC P0653     **Sensor Reference Voltage B High**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply above 5.4 volts
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Normally this fault will set in the case of a wiring fault. Check for a short circuit to battery voltage, or an open circuit in a sensor ground wire.

### 3.129 DTC P0654     **Engine Speed Output Circuit Fault**

The ECM controls the tachometer in the instrument cluster. This DTC indicates that the tachometer driver circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Tachometer output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify wiring between ECM and tachometer. In particular, check for short circuits to power and/or ground.

---

### 3.130 DTC P0655 Overheat Lamp Circuit Fault

The ECM uses the overheat lamp to call attention to an overheat condition. This DTC indicates that the overheat lamp circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Engine overheat lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C1.

- Immediate DTC set
- Immediate MIL illumination
- No freeze-frame data will be stored
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### 3.131 DTC P0656 Fuel Level Output Circuit Fault

The ECM can control the fuel gauge in the instrument cluster directly. This DTC indicates that the gauge driver circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Fuel Gauge output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

---

- 
- Immediate DTC set
  - No freeze-frame data will be stored
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify wiring between injector and fuel gauge. In particular, check for short circuits to power and/or ground.

### 3.132 DTC P0657 Actuator Power Control Relay Circuit Open

The control circuit to the power relay is tested for continuity. A faulty actuator power control relay or wiring problems will typically cause this DTC to set. This DTC is used when ECM power and actuator power relays are separate. When the functions are combined, only DTC P0686/P0687 will be used.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.

### 3.133 DTC P0658 Actuator Power Voltage Low

Actuator power voltage is monitored for fuel injector pulse width correction and voltage diagnostics. This diagnostic indicates that the actuator power supply is lower than expected, and may be caused by a low system voltage, an actuator power relay fault or a blown fuse.

---

Flash code:

Conditions to run test:

- Actuator power relay commanded on
- Actuator power signal voltage lower than (key power voltage - 1.5 volts)
- Condition exists for two seconds

DTC Logic: Type A1

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure main power relay is operational.
- Check power supply and fusing to main power relay.
- This fault may be caused by a stuck-open main power relay.

### **3.134 DTC P0659 Actuator Power Voltage High**

Actuator power voltage is monitored for fuel injector pulse width correction and voltage diagnostics. This diagnostic indicates that the actuator power supply is higher than expected, and may be caused by a high system voltage, an actuator power relay fault, or a wiring problem.

Flash code:

Conditions to run test:

- Actuator power relay commanded off
- Actuator power signal voltage greater than (key power voltage – 1.5 volts)
- Condition exists for two seconds

OR

- Actuator power relay commanded on
- Actuator power signal voltage greater than (key power voltage + 1.5 volts)
- Condition exists for two seconds

DTC Logic: Type A1

- Immediate DTC stored

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Ensure main power relay is operational.
- Check battery and alternator for proper operation.
- This fault may be caused by a stuck-on actuator power relay.

### 3.135 DTC P0686 Power Control Relay Circuit Low

The control circuit to the power relay is tested for continuity. A faulty actuator power control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.



---

### 3.136 DTC P0687 Power Control Relay Circuit High

The control circuit to the power relay is tested for continuity and short circuits. A faulty actuator power control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the relay coil
- Verify wiring between relay and ECM
- Verify keyed power is present at the relay coil.
- A short circuit in the relay coil or wiring may cause this fault.

### 3.137 DTC P0691 Fan 1 Relay Control Circuit Low

The control circuit to the Fan 1 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan output commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

---

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify power is present at the relay coil.

### 3.138 DTC P0692 Fan 1 Relay Control Circuit High

The control circuit to the Fan 1 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan control relay commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the relay coil
- Verify wiring between relay and ECM
- Verify power is present at the relay coil.

- 
- A short circuit in the relay coil or wiring may cause this fault.

### **3.139 DTC P0693 Fan 2 Relay Control Circuit Low**

The control circuit to the Fan 2 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan output commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the relay coil
- Verify wiring between relay and ECM
- Verify power is present at the relay coil.

### **3.140 DTC P0694 Fan 2 Relay Control Circuit High**

The control circuit to the Fan 2 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan control relay commanded on

- 
- Output driver IC records high voltage fault (short to power)
  - Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the relay coil
- Verify wiring between relay and ECM
- Verify power is present at the relay coil.
- A short circuit in the relay coil or wiring may cause this fault.

### 3.141 DTC P0695 Fan 3 Relay Control Circuit Low

The control circuit to the Fan 3 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan output commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

---

- 
- Verify continuity of the relay coil
  - Verify wiring between relay and ECM
  - Verify power is present at the relay coil.

### **3.142 DTC P0696 Fan 3 Relay Control Circuit High**

The control circuit to the Fan 3 control relay is tested for continuity. A faulty fan control relay or wiring problems will typically cause this DTC to set.

Flash code:

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fan control relay commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the relay coil
- Verify wiring between relay and ECM
- Verify power is present at the relay coil.
- A short circuit in the relay coil or wiring may cause this fault.

### **3.143 DTC P0698 Sensor Reference Voltage C Low**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply below 4.6 volts

- 
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Wiring faults or defective sensors may cause this fault.
- Some versions of control modules (first production A31) cannot measure the analogue voltage level. Troubleshoot these modules using a voltmeter.
- To isolate a defective sensor, disconnect all sensors powered from the Sensor Reference Voltage C power supply, while monitoring the sensor power supply either on a scan tool or with a voltmeter. When the defective sensor is plugged back in, the voltage will fall. Replace that sensor.

### **3.144 DTC P0699      Sensor Reference Voltage C High**

Sensor power voltage is monitored for short circuits to ground or power.

Flash code: none

Conditions to run test:

- Sensor power supply above 5.4 volts
- Condition exists for 0.3 second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Normally this fault will set in the case of a wiring fault. Check for a short circuit to battery voltage, or an open circuit in a sensor ground wire.



---

### 3.145 DTC P1134 Oxygen Sensor 1, Bank 1, Erratic Air-Fuel Ratio

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. For proper driveability and emissions performance, the sensor must respond to air-fuel ratio changes properly and reliably. This diagnostic checks the response time of the lambda sensor to a change in the oxygen sensor voltage. An inconsistent sensor signal may result in poor emissions and driveability.

Flash code: none

Conditions to run test:

- Oxygen sensor time delay ratio (rich vs. lean switch times) more than 0.75 or less than -0.75.
- Condition exists for 30 consecutive crosses
- Diagnostic threshold uses an up-down counter to avoid false diagnostic failures and false diagnostic passes
- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault
- No ECTS fault
- No IATS fault
- No misfire recorded
- No injector circuit fault
- Greater than 5% fuel remaining in storage
- Oxygen sensor warm

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC is usually caused by a degraded oxygen sensor.
- Before replacing the oxygen sensor, check for engine misfire which may set this DTC.
- Before replacing the oxygen sensor, check for exhaust system leaks.

---

### 3.146 DTC P1135 Oxygen Sensor 1, Bank 1, Oxygen Sensor Lean Shift

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. For proper driveability and emissions performance, the sensor must respond to air-fuel ratio changes properly and reliably. This diagnostic checks the response time of the lambda sensor to a change in the oxygen sensor voltage. A shifted signal will affect emissions.

Note that method B test values are available using test retrieval via ISO14230, service 0x06. Please refer to the Mode 6 summary.

Accumulated oxygen sensor cross data is kept in non-volatile memory so that a sequence of shorter vehicle trips will eventually cause this monitor to run.

Flash code: none

Conditions to run test:

- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault
- No ECTS fault
- No IATS fault
- No misfire recorded
- No injector circuit fault
- Greater than 5% fuel quantity remaining
- Oxygen sensor warm
- Engine speed is above 2000 RPM
- Vehicle speed is above 20 km/h
- Manifold pressure is above 70 kPa<sub>a</sub>

Method A:

- Oxygen sensor time delay ratio (rich vs. lean switch times) less than -0.75.
- Condition exists for 40 consecutive crosses
- Diagnostic threshold uses an up-down counter to avoid false diagnostic failures and false diagnostic passes

OR Method B:

- Oxygen sensor time delay average ratio (rich vs. lean switch times) less than -0.375.
- Averaged time delay values are calculated over 512 crosses

- 
- Transients will stop the collection of data until steady-state conditions return

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This DTC is usually caused by a degraded oxygen sensor.
- Before replacing the oxygen sensor, check for engine misfire which may set this DTC.
- Before replacing the oxygen sensor, check for exhaust system leaks.

### 3.147 DTC P1136 Oxygen Sensor 1, Bank 1, Oxygen Sensor Rich Shift

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. For proper driveability and emissions performance, the sensor must respond to air-fuel ratio changes properly and reliably. This diagnostic checks the response time of the lambda sensor to a change in the oxygen sensor voltage. A shifted signal will affect emissions.

Note that method B test values are available using test retrieval via ISO14230, service 0x06. Please refer to the Mode 6 summary.

Accumulated oxygen sensor cross data is kept in non-volatile memory so that a sequence of shorter vehicle trips will eventually cause this monitor to run.

Flash code: none

#### Conditions to run test:

- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault
- No ECTS fault
- No IATS fault
- No misfire recorded
- No injector circuit fault
- Greater than 5% fuel quantity remaining
- Oxygen sensor warm

- 
- Engine speed is above 2000 RPM
  - Vehicle speed is above 20 km/h
  - Manifold pressure is above 70 kPa<sub>a</sub>

Method A:

- Oxygen sensor time delay ratio (rich vs. lean switch times) greater than +0.75.
- Condition exists for 40 consecutive crosses
- Diagnostic threshold uses an up-down counter to avoid false diagnostic failures and false diagnostic passes

OR Method B:

- Oxygen sensor time delay average ratio (rich vs. lean switch times) greater than 0.375.
- Averaged time delay values are calculated over 512 crosses
- Transients will stop the collection of data until steady-state conditions return

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC is usually caused by a degraded oxygen sensor.
- Before replacing the oxygen sensor, check for engine misfire which may set this DTC.
- Before replacing the oxygen sensor, check for exhaust system leaks.

### **3.148 DTC P1137    Oxygen Sensor 1, Bank 1, Oxygen Sensor High Impedance**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. This test attempts to determine if an oxygen sensor has degraded by measuring its circuit impedance. It does this by briefly sending a current into the sensor and monitoring the sensor output.

Not all ECM models are capable of measuring oxygen sensor impedance. These control modules will not report mode 6 data for oxygen sensor impedance, and will not set this DTC.

Test values are available using test retrieval via ISO14230, service 0x06. Please refer to the Mode 6 summary.

Flash code: none

---

---

Conditions to run test:

- Short-term fuel trim not approaching upper or lower limits
- No MAP sensor fault
- No TPS fault
- No ECTS fault
- No IATS fault
- No misfire recorded
- No injector circuit fault
- Greater than 5% fuel quantity remaining
- Oxygen sensor warm
- At least 90 seconds of engine run time has elapsed
- Coolant temperature needs to be greater than -11 degrees C
- Measured planar oxygen sensor impedance is above 2000 ohms

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC is usually caused by a degraded oxygen sensor.

### **3.149 DTC P1138 Oxygen Sensor 1, Bank 1, Oxygen Sensor Overheat Condition**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. On some applications, a wide-range sensor (UEGO) is used. The temperature of the sensor tip must be maintained at a constant temperature of 700 degrees C to operate properly. The sensor may be damaged if it overheats. If the temperature rises above approximately 850 degrees C, this DTC will set.

Flash code: none

Conditions to run test:

- Engine running
- No oxygen sensor heater circuit fault

- 
- Measured UEGO oxygen sensor impedance is below 75 ohms
  - Condition exists for 15 seconds

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This DTC may be caused by a degraded oxygen sensor.
- This DTC may be caused by a short circuit in the heater control circuit.
- This DTC may be caused by excessive engine exhaust temperatures.

### **3.150 DTC P1517 Backup TPS Data Does Not Match**

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. If, after this process, the backup and primary span data differ by an excessive amount, this DTC will set.

Flash code: none

Conditions to run test:

- Throttle span process completed
- Backup and primary data differs by more than 20 mV
- These conditions need to occur four times in a row to set this DTC

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault



---

#### Troubleshooting Hints:

- Check throttle for proper motion, and for debris or overhanging gaskets using the procedure found in DTC P0638
- If throttle motion and control is adequate, perform manual throttle zero process using scan tool.

### **3.151 DTC P1518     Unable to complete throttle zero process**

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. If this process cannot complete, this DTC will set.

Flash code: none

#### Conditions to run test:

- Engine stopped, key off
- Either throttle position sensor shorted to power or ground OR
- The throttle rest position on both inputs are not between 5% and 35% OR
- A minimum voltage change of 3.5 volts has not been achieved on both inputs during the span process

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Troubleshoot and repair any sensor power supply faults first.
- Troubleshoot and repair any TPS faults first.
- Check throttle for proper motion, and for debris or overhanging gaskets using the procedure found in DTC P0638. Check for proper throttle position voltage readings.
- If throttle motion and control is adequate, perform manual throttle zero process using scan tool.

---

### 3.152 DTC P1519    **No Backup TPS Zero Data Found**

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. This process generates two copies of this data in EEPROM. If only one copy is found, the engine will run normally but either DTC P1519 or P1520 will set. If both DTC's are set, the engine will only run in the default fast-idle throttle position.

Flash code: none

Conditions to run test:

- ECM restart (key on)
- EEPROM does not show a valid TPS zero record in the backup memory area

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This indication is normal on a new ECM installation. Clear DTC's if the throttle is working normally.
- If the DTC reappears, check battery backup power for proper operation. It must not be disconnected from the battery.

### 3.153 DTC P1520    **No Primary TPS Zero Data Found**

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. This process generates two copies of this data in EEPROM. If only one copy is found, the engine will run normally but either DTC P1519 or P1520 will set. If both DTC's are set, the engine will only run in the default fast-idle throttle position.

Flash code: none

Conditions to run test:

---

- 
- ECM restart (key on)
  - EEPROM does not show a valid TPS zero record in the primary memory area

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This indication is normal on a new ECM installation. Clear DTC's if the throttle is working normally.
- If the DTC reappears, check battery backup power for proper operation. It must not be disconnected from the battery.

### **3.154 DTC P1521 Throttle Resting Position Incorrect**

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. If this process cannot complete, this DTC will set.

Flash code: none

#### Conditions to run test:

- Engine stopped, key off
- The throttle rest position on both inputs are not between 5% and 35%

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault

- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Troubleshoot and repair any sensor power supply faults first.
- Troubleshoot and repair any TPS faults first.
- Check throttle for proper motion, and for debris or overhanging gaskets using the procedure found in DTC P0638. Check for proper throttle position voltage readings.
- If throttle motion and control is adequate, perform manual throttle zero process using scan tool.

### 3.155 DTC P1522 Throttle Resting Position Incorrect After Span

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. After this process has completed, the resting positions are compared – they should match. A failed match indicates the two sensors have drifted apart or the sensor may be miswired.

Flash code: none

#### Conditions to run test:

- Engine stopped, key off
- The throttle rest position on both inputs match within 5%.

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Troubleshoot and repair any sensor power supply faults first.
- Troubleshoot and repair any TPS faults first.
- Check throttle for proper motion, and for debris or overhanging gaskets using the procedure found in DTC P0638. Check for proper throttle position voltage readings.

- 
- If throttle motion and control is adequate, perform manual throttle zero process using scan tool.

### **3.156 DTC P1524 Low Oil Pressure Lamp Circuit Fault**

The ECM uses the low oil pressure lamp to call attention to a loss in engine oil pressure. If the driver responds quickly to this lamp, metal collected in the crankcase may be minimised. This DTC indicates that the low oil pressure lamp circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Low oil pressure lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### **3.157 DTC P1525 Customer-Specific Lamp Circuit A Fault**

This DTC indicates that the customer-specific lamp circuit has a fault. The function of this lamp depends on the customer application.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Customer-specific lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

---

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### **3.158 DTC P1526    Customer-Specific Lamp Circuit B Fault**

This DTC indicates that the customer-specific lamp circuit has a fault. The function of this lamp depends on the customer application.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Customer-specific lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.



---

### 3.159 DTC P1560 Low Coolant Level Lamp Circuit Fault

The ECM uses the low coolant level lamp to call attention to a loss in engine coolant. This DTC indicates that the low coolant level lamp circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Low coolant level lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C3.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### 3.160 DTC P1609 Calibration/Firmware Mismatch

The ECM firmware and calibration files are stored in flash memory. They can be updated separately. If the firmware file is updated but is not compatible with the calibration file stored in flash memory, this DTC will set. The ECM should be updated first with new firmware, then with new calibration if this fault occurs.

Flash code: none

Conditions to run test:

- ECM Power-up cycle

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

### **3.161 DTC P1630/P1631      Electronic Throttle Driver Overheat**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver overheats, this DTC will set. Frequent operation in these temperature regions will result in ECM reliability reduction.

Flash code: none

Conditions to run test:

- Engine running
- Throttle driver temperature exceeds 140 degrees C

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- With the throttle motor disconnected, verify throttle moves smoothly and without excessive force required. Check throttle for binding.
- Note that the throttle blades are sharp. Be very cautious of moving the throttle plate manually. Do not move the throttle while connected to the ECM. The ECM may move the throttle blade even with the ignition key off.
- Check the placement of the ECM to ensure it is not getting overheated.

### **3.162 DTC P1632      Electronic Throttle Driver Overheat Shutdown**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver overheats and is forced to shut down, this DTC will set. Frequent operation in these temperature regions will result in ECM reliability reduction.

Flash code: none

---

---

Conditions to run test:

- Engine running
- Throttle driver temperature exceeds 180 degrees C

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- With the throttle motor disconnected, verify throttle moves smoothly and without excessive force required. Check throttle for binding.
- Note that the throttle blades are sharp. Be very cautious of moving the throttle plate manually. Do not move the throttle while connected to the ECM. The ECM may move the throttle blade even with the ignition key off.
- Check the placement of the ECM to ensure it is not getting overheated.

### **3.163 DTC P1633      Electronic Throttle Driver Overvoltage Shutdown**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver has a high voltage applied to it, and is forced to shut down, this DTC will set.

Flash code: none

Conditions to run test:

- Engine running
- Throttle driver voltage exceeds 37 volts (34 – 40 volt tolerance)
- Condition exists for 3 ms

DTC Logic: Type A1

- Emissions related
  - Likely immediate driveability and emissions effects
  - Immediate DTC stored
-

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check wiring, alternator, and battery for proper operation.

### **3.164 DTC P1655 Coolant Temperature Output Circuit Fault**

The ECM can control the temperature gauge in the instrument cluster directly. This DTC indicates that the gauge driver circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Temperature Gauge output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify wiring between ECM and temperature gauge. In particular, check for short circuits to power and/or ground.

### **3.165 DTC P1656 Low Fuel Lamp Circuit Fault**

The ECM uses the low fuel lamp to call attention to a potential tow or push condition. This DTC indicates that the low fuel lamp circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Low fuel lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C1.

---

- 
- Immediate DTC set
  - No freeze-frame data will be stored
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

### **3.166 DTC P1657 Stop Engine Lamp Circuit Fault**

The ECM uses the stop engine lamp to call attention to a potential engine or vehicle-damaging condition. This DTC indicates that this lamp circuit has a fault.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Stop engine lamp output driver reports a circuit fault (open load or shorted load)
- Conditions exist for 0.3 seconds

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify the indicator lamp is not burnt out (incandescent lamps)
- Verify wiring between lamp and ECM
- Verify ignition key switched power (active in start and run modes) is used to power the indicator lamp.
- Verify that a parallel resistance is included when an LED-based indicator lamp is in use. This ensures the pin diagnostic function works correctly, and that the LED does not glow dimly when the lamp should be off.

---

### 3.167 DTC P1661 Internal Power Supply Voltage Low

Some engine control modules contain a two-stage voltage regulator. If the first stage of this voltage regulator is not operating correctly, this DTC will set.

Flash code: none

Conditions to run test:

- Internal power supply below 5.4 volts
- Condition exists for 0.3 second

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

### 3.168 DTC P1662 Internal Power Supply Voltage High

Some engine control modules contain a two-stage voltage regulator. If the first stage of this voltage regulator is not operating correctly, this DTC will set.

Flash code: none

Conditions to run test:

- Internal power supply above 7.5 volts
- Condition exists for 0.3 second

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

### 3.169 DTC P1666 Fuel Shutoff C Solenoid Circuit Low

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fuel Shutoff Solenoid C commanded off



- 
- Output driver IC records low voltage fault (short to ground or open load)
  - Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.

### **3.170 DTC P1667 Fuel Shutoff C Solenoid Circuit High**

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fuel shutoff solenoid C output commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

---

- 
- Verify continuity and resistance of the solenoid coil
  - Verify wiring between solenoid and ECM
  - Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.

### **3.171 DTC P1690      Maintenance Reminder**

This DTC sets when the fuel system is due for maintenance.

Flash code: none

Conditions to run test:

- Maintenance fuel used exceeds programmed limit OR
- Distance driven exceeds programmed limit OR
- Injector cycle count exceeds programmed limit OR
- Engine run time exceeds programmed limit

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault
- Service lamp may be set to illuminate with this DTC

Troubleshooting Hints

- This DTC indicates that some components of the fuel system need to be checked for proper operation or replaced.

### **3.172 DTC P2096      Post Catalyst Fuel Trim System Too Lean**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. To maintain the average air-fuel ratio to within 0.1%, the post-catalyst oxygen sensor is monitored and the front oxygen sensor set point is modified to maintain the post-catalyst oxygen sensor at a predetermined voltage level. If the front oxygen sensor set point has been modified by the post-catalyst controller but has not been able to achieve the proper post-catalyst oxygen sensor voltage level, this DTC will set.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled

- 
- Fuel trims not at programmed limits
  - Post-catalyst fuel correction factor at programmed limit
  - Post-catalyst oxygen sensor voltage lower than set point
  - Condition exists for at least 20 consecutive seconds
  - Condition exists for a total of 250 seconds
  - No MAP sensor fault detected
  - No TPS fault detected
  - No ECTS fault detected
  - No IATS fault detected
  - No misfiring fault detected
  - No injector circuit fault detected
  - No fuel level sensor fault detected
  - Above 5% fuel storage quantity
  - Engine not operating in idle region
  - Calculated load value lower than 75%

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for exhaust leaks, which may cause this DTC to set.
- Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.

### **3.173 DTC P2097 Post Catalyst Fuel Trim System Too Rich**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. To

---

maintain the average air-fuel ratio to within 0.1%, the post-catalyst oxygen sensor is monitored and the front oxygen sensor set point is modified to maintain the post-catalyst oxygen sensor at a predetermined voltage level. If the front oxygen sensor set point has been modified but has not been able to achieve the proper post-catalyst oxygen sensor voltage level, this DTC will set.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Fuel trims not at programmed limits
- Post-catalyst fuel correction factor at programmed limit
- Post-catalyst oxygen sensor voltage higher than set point
- Condition exists for at least 20 consecutive seconds
- Condition exists for a total of 250 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Engine not operating in idle region
- Calculated load value lower than 75%

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.

- 
- Check for exhaust leaks, which may cause this DTC to set.
  - Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.

### **3.174 DTC P2100 Throttle Actuator Control Motor Circuit Open**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver indicates there is insufficient load, this DTC will set. A P0638 DTC will also typically set because an open motor circuit cannot be controlled properly.

Flash code: none

Conditions to run test:

- Engine running
- Throttle driver current below 130 mA
- Commanded duty cycle greater than 16.4%

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Check throttle wiring for continuity or short circuits.
- Check motor for continuity. If open, replace the throttle.
- Check throttle for smoothness of operation using the procedure noted for DTC P0638.
- If the fault repeatedly occurs, replace throttle assembly.

### **3.175 DTC P2102 Throttle Actuator Control Motor Circuit Low**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver indicates one of the motor control wires is shorted to ground (or

---

to the other motor control wire), this DTC will set. A P0638 DTC will also typically set because an shorted motor circuit cannot be controlled properly. In some cases, throttle damage may occur.

Flash code: none

Conditions to run test:

- Engine running
- Throttle driver indicates short to ground

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Check throttle wiring for continuity or short circuits.
- Check motor for continuity. If open, replace the throttle.
- Check throttle for smoothness of operation using the procedure noted for DTC P0638.
- If the fault repeatedly occurs, replace throttle assembly.

### **3.176 DTC P2103 Throttle Actuator Control Motor Circuit High**

The electronic throttle assembly includes a brushed DC electric motor and reducing gearbox used to position the throttle. This motor requires a bidirectional driver capable of supplying up to six amperes of current to the motor. If this driver indicates one of the motor control wires is shorted to battery power (or to the other motor control wire), this DTC will set. A P0638 DTC will also typically set because a shorted motor circuit cannot be controlled properly. In some cases, throttle damage may occur.

Flash code: none

Conditions to run test:

- Engine running
- Throttle driver indicates short to ground

DTC Logic: Type A1

- Emissions related



- 
- Likely immediate driveability and emissions effects
  - Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Check throttle wiring for continuity or short circuits.
- Check motor for continuity. If open, replace the throttle.
- Check throttle for smoothness of operation using the procedure noted for DTC P0638.
- If the fault repeatedly occurs, replace throttle assembly.

### **3.177 DTC P2111 Throttle Stuck Open**

If the throttle is stuck open, this DTC will set. It usually indicates throttle gearbox or bore damage, however, sometimes contamination in the throttle bore can cause this. Normally, this DTC triggers an engine shutdown by disabling fuel injection to the engine.

Flash code: none

#### Conditions to run test:

- No sensor power supply fault recorded
- Throttle position measured is above 95%
- Throttle duty cycle is below -25% (trying to close throttle)
- Condition exists for one second

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- 
- This fault usually indicates the throttle is jammed open against its wide-open stop. If the throttle is stuck while disconnected from the ECM, replace the throttle assembly.
  - If the throttle returns to the default (fast idle position) while disconnected from the ECM, check the wiring first. If the wiring is ok, then replace the ECM.

### **3.178 DTC P2112 Throttle Stuck Closed**

If the throttle is stuck closed, this DTC will set. It usually indicates throttle gearbox or bore damage, however, sometimes contamination in the throttle bore can cause this.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position measured is below 3.1%
- Throttle duty cycle is above 25% (trying to open throttle)
- Condition exists for one second

DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This fault usually indicates the throttle is jammed open against the throttle bore. If the throttle is stuck while disconnected from the ECM, replace the throttle assembly.
- If the throttle returns to the default (fast idle position) while disconnected from the ECM, check the wiring first. If the wiring is ok, then replace the ECM.

### **3.179 DTC P2122 Accelerator Pedal Position Sensor D Low**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

---

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### **3.180 DTC P2123 Accelerator Pedal Position Sensor D High**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

---

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### **3.181 DTC P2127 Accelerator Pedal Position Sensor E Low**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal below 0.1 volts

- 
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### **3.182 DTC P2128 Accelerator Pedal Position Sensor E High**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

---

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### **3.183 DTC P2132 Accelerator Pedal Position Sensor F Low**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal below 0.1 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored



- 
- After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.184 DTC P2133 Accelerator Pedal Position Sensor F High

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy; however, some systems only use a single sensor and an idle switch.

An open circuit or a short circuit to ground on this sensor signal will generate this fault. An open circuit on the sensor power supply can cause this fault as well.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signal above 4.9 volts
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

---

## Troubleshooting Hints

- Check for sensor power supply fault. Troubleshoot first.
- Disconnect sensor. Verify position sensor voltage reads 0 V. If not, check sensor signal for short circuit to another signal.
- Check for +5 V sensor power and sensor ground for continuity and/or voltage.
- Jumper across harness sensor (sensor power to sensor signal). Verify sensor voltage reads 5 V. If not, check harness for continuity.
- Check resistance of sensor (all terminals). Verify that it is within specifications.

### 3.185 DTC P2135 Throttle Position Sensor A-B Correlation

The ECM utilizes throttle position information to predict airflow into the engine during a transient condition, for idle speed control and for many auxiliary functions. In an electronic throttle control (ETC) system, this sensor is used as the primary feedback mechanism to control airflow through the engine. ETC systems will use at least two throttle position sensors for redundancy.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Throttle position signals A and B indicate a difference of greater than 5%
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This fault usually indicates a performance or wiring problem with the accelerator pedal position sensor.
- Check wiring and the output of the sensor for proper signals. If these do not work correctly, then replace the sensor.

---

### 3.186 DTC P2138 Accelerator Pedal Position Sensor D-E Correlation

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy, however, some systems only use a single sensor and an idle switch.

If accelerator pedal inputs D and E do not match, this DTC will set. In the case of an idle validation switch plus single sensor system, this DTC indicates that the idle validation switch does not match the accelerator pedal position voltage.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal D and E differ by more than 15%
- Condition exists for one second

OR

- No sensor power supply fault is recorded
- Accelerator pedal position signal D records a value of greater than 10% while the idle validation signal indicates a voltage greater than 2.5 volts (open)

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This fault usually indicates a performance or wiring problem with the accelerator pedal position sensor.
- Check wiring and the output of the sensor for proper signals. If these do not work correctly, then replace the sensor.

---

### 3.187 DTC P2139 Accelerator Pedal Position Sensor D-F Correlation

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy; however, some systems only use a single sensor and an idle switch.

If accelerator pedal inputs D and F do not match, this DTC will set. This only applies to triple-potentiometer accelerator pedal position sensors.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal D and F differ by more than 15%
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This fault usually indicates a performance or wiring problem with the accelerator pedal position sensor.
- Check wiring and the output of the sensor for proper signals. If these do not work correctly, then replace the sensor.

### 3.188 DTC P2139 Accelerator Pedal Position Sensor E-F Correlation

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy; however, some systems only use a single sensor and an idle switch.

If accelerator pedal inputs E and F do not match, this DTC will set. This only applies to triple-potentiometer accelerator pedal position sensors.

Flash code: none

---

Conditions to run test:

- No sensor power supply fault recorded
- Accelerator pedal position signal E and F differ by more than 15%
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- If a backup sensor is available, that input will be used instead
- If no backup sensor is available, the engine will only be allowed to idle

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This fault usually indicates a performance or wiring problem with the accelerator pedal position sensor.
- Check wiring and the output of the sensor for proper signals. If these do not work correctly, then replace the sensor.

### **3.189 DTC P2172 Sudden High Airflow Detected**

If the throttle is commanded to a low position and the intake air estimator indicates a high airflow has started suddenly, this DTC will set. It may indicate either throttle body damage or a sudden air leak between the throttle and engine.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Estimated airflow from manifold pressure suddenly increases by more than 35% above the previous average value
- Commanded torque has not changed more than 5%
- Condition exists for 250 milliseconds
- No P2173 present
- More than 2 seconds of engine running time

---

Actions taken when fault is detected in an ETC system:

- The throttle will be commanded to the default position
- If the high airflow and torque estimate continues, fuel will be cut off to maintain the engine speed at a fast idle.

DTC Logic: Type A1

- Emissions and Safety related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check operation of the throttle for sticking.
- Check the intake system for leaks

### **3.190 DTC P2173 High Airflow Detected**

If the throttle is commanded to a low position and the intake air estimator indicates a high airflow is occurring, this DTC will set. It may indicate either throttle body damage or an air leak between the throttle and engine.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Desired airflow used to determine throttle position lower than the estimated airflow using manifold pressure or mass air flow estimators by more than 25%
- Commanded torque below 60%
- Commanded torque has not changed more than 5%
- Condition exists for 500 milliseconds
- No P2172 present
- More than 2 seconds of engine running time

Actions taken when fault is detected in an ETC system:

- The throttle will be commanded to the default position



- 
- If the high airflow and torque estimate continues, fuel will be cut off to maintain the engine speed at a fast idle.

DTC Logic: Type A1

- Emissions and Safety related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check operation of the throttle for sticking.
- Check the intake system for leaks

### **3.191 DTC P2174 Sudden Low Airflow Detected**

If the throttle is commanded to a high position and the intake air estimator indicates a low airflow has started suddenly, this DTC will set. It may indicate either throttle body damage or a sudden air blockage anywhere in the air intake system.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Estimated airflow from manifold pressure suddenly decreases by more than 35% below the previous average value
- Commanded torque has not changed more than 5%
- P2175 not present
- More than 2 seconds of engine running time
- Condition exists for 250 milliseconds

Actions taken when fault is detected in an ETC system:

- The throttle will be commanded to the default position

DTC Logic: Type A1

- Emissions and Safety related
- Likely immediate driveability and emissions effects

- 
- Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check operation of the throttle for sticking.
- Check the intake system for blockage

### 3.192 DTC P2175 Low Airflow Detected

If the throttle is commanded to a low position and the intake air estimator indicates a low airflow is occurring, this DTC will set. It may indicate either throttle body damage or a blockage anywhere in the air intake system.

Flash code: none

Conditions to run test:

- No sensor power supply fault recorded
- Desired airflow used to determine throttle position greater than the estimated airflow using manifold pressure or mass air flow estimators by more than 50%
- Commanded torque below 60%
- Commanded torque has not changed more than 5%
- P2174 not present
- More than 2 seconds of engine running time
- Condition exists for one second

Actions taken when fault is detected in an ETC system:

- The throttle will be commanded to the default position

DTC Logic: Type A1

- Emissions and Safety related
  - Likely immediate driveability and emissions effects
  - Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
-

- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check operation of the throttle for sticking.
- Check the intake system for leaks

### 3.193 DTC P2176 Idle Position Not Learned

In electronic throttle systems, the ECM needs to maintain zero and full-throttle position voltage levels to translate that into a relative opening value. This relative opening value is used to control throttle position, and also in the airflow estimator. After key-off, the throttle will be gradually closed, then gradually opened, in order to find the limits. If this process cannot complete, this DTC will set.

Flash code: none

#### Conditions to run test:

- Engine stopped, key off
- Either throttle position sensor shorted to power or ground OR
- The throttle rest position on both inputs are not between 5% and 35% OR
- A minimum voltage change of 3.5 volts has not been achieved on both inputs during the span process

#### DTC Logic: Type A1

- Emissions related
- Likely immediate driveability and emissions effects
- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Troubleshoot and repair any sensor power supply faults first.
- Troubleshoot and repair any TPS faults first.
- Check throttle for proper motion, and for debris or overhanging gaskets using the procedure found in DTC P0638. Check for proper throttle position voltage readings.
- If throttle motion and control is adequate, perform manual throttle zero process using scan tool.

---

### 3.194 DTC P2177 Fuel System Too Lean off-Idle, Bank 1

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the off-idle region is attempting to add as much fuel as the programmed maximum value (typically around 15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at upper limit (typically 15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Engine not operating in idle region
- Calculated load value lower than 75%

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for exhaust leaks, which may cause this DTC to set.

- 
- Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.

### 3.195 DTC P2178 Fuel System Too Rich off-Idle, Bank 1

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the off-idle region is attempting to subtract as much fuel as the programmed minimum value (typically around -15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at lower limit (typically -15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Engine not operating in idle region
- Calculated load value lower than 75%

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
-

- 
- Check fuel quality to ensure that it meets the appropriate specifications.
  - Check for leaking injectors. This can be done by pressurizing the fuel rail and listening for escaping gas. All CNG injectors leak a small amount, but it should not be audible.
  - Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.
  - Occasionally, silicone or oil contamination of an oxygen sensor may cause this DTC.

### **3.196 DTC P2187 Fuel System Too Lean at Idle, Bank 1**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the idle region is attempting to add as much fuel as the programmed maximum value (typically around 15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at upper limit (typically 15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Engine operating in idle region

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault



- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for exhaust leaks. These may cause this DTC to set.
- Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.

### 3.197 DTC P2188 Fuel System Too Rich at Idle, Bank 1

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the idle region is attempting to subtract as much fuel as the programmed minimum value (typically around -15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at lower limit (typically -15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Engine operating in idle region

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.

- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for leaking injectors. This can be done by pressurizing the fuel rail and listening for escaping gas. All CNG injectors leak a small amount, but it should not be audible.
- Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.
- Occasionally, silicone or oil contamination of an oxygen sensor may cause this DTC.

### 3.198 DTC P2191 Fuel System Too Lean At High Load, Bank 1

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the high-load region is attempting to add as much fuel as the programmed maximum value (typically around 15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at upper limit (typically 15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Above 5% fuel storage quantity
- Calculated load value higher than 75%

DTC Logic: Type B

---

- 
- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for exhaust leaks, which may cause this DTC to set.
- Check pressure regulator for proper performance.
- Check fuel system filters for restriction.
- Ensure shutoff valves are not only opening partially.
- This DTC may set in the case of an overheated oxygen sensor.

### **3.199 DTC P2192 Fuel System Too Rich At High Load, Bank 1**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. Adaptive learning is used to adjust for air or fuel variation due to engine, fuel, or fuel metering component differences. If the adaptive fuel trim in the high-load region is attempting to subtract as much fuel as the programmed minimum value (typically around -15%), this DTC will indicate this problem.

Flash code: none

Conditions to run test:

- Long-term fuel trim enabled
- Short-term fuel trim at lower limit (typically -15%)
- Condition exists for 20 seconds
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected

- 
- No fuel level sensor fault detected
  - Above 5% fuel storage quantity
  - Calculated load value higher than 75%

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check for misfire and other DTC's first. They may cause this DTC to set.
- Check fuel quality to ensure that it meets the appropriate specifications.
- Check for leaking injectors. This can be done by pressurizing the fuel rail and listening for escaping gas. All CNG injectors leak a small amount, but it should not be audible.
- At high load, a rich indication may indicate excessive exhaust backpressure or other engine breathing issues.
- Usually this DTC is not caused by a faulty oxygen sensor. If no other causes are found, check the oxygen sensor for proper operation.
- Occasionally, silicone or oil contamination of an oxygen sensor may cause this DTC.

### **3.200 DTC P2195 Oxygen Sensor 1, Bank 1, Signal Stuck Lean**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. If the voltage remains low but still in-range, this DTC will set. This DTC is likely caused by problems other than the oxygen sensor – exhaust leaks or misfires are likely causes.

Flash code: none

Conditions to run test:

- Engine operating in closed loop mode
- Oxygen sensor voltage under 0.073 volts
- Condition exists for 22 seconds
- No previous P0131, P2191, P2187, P2192, P2188, P2178, P0134, or P2177
- No MAP sensor fault detected
- No TPS fault detected

- 
- No ECTS fault detected
  - No IATS fault detected
  - No misfiring fault detected
  - No injector circuit fault detected
  - No fuel level sensor fault detected
  - Above 5% fuel storage quantity

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- This DTC is usually caused by engine or plumbing issues such as misfires, exhaust leaks, and engine damage.
- Occasionally, a damaged oxygen sensor may set this DTC.

### **3.201 DTC P2196    Oxygen Sensor 1, Bank 1, Signal Stuck Rich**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. If the oxygen sensor signal is likely valid but reading rich continually, this DTC will set.

Flash code: none

#### Conditions to run test:

- Engine operating in closed loop mode
  - Oxygen sensor voltage above 0.830 volts
  - Condition exists for 22 seconds
  - No MAP sensor fault detected
  - No TPS fault detected
  - No ECTS fault detected
  - No IATS fault detected
  - No misfiring fault detected
  - No injector circuit fault detected
-

- 
- No fuel level sensor fault detected
  - Above 1.25 MPa fuel storage pressure
  - No previous P0131, P2191, P2187, P2192, P2188, P2178, P0134, or P2177

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- This DTC is usually set by engine or fuel system problems, such as high fuel pressure, leaking fuel injectors, or engine breathing issues.
- Occasionally this DTC may set in the case of oil, silicone, or glycol contamination.

### 3.202 DTC P2231 Oxygen Sensor 1, Bank 1, Shorted to Heater

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. Since the cell heater is in close proximity to the sensor cell, a potential exists for a short circuit between the heater and the sensor cell.

Flash code: none

Conditions to run test:

- UEGO sense signal greater than 4.9 volts
- Condition exists for one second

OR

- Planar O2 sensor signal greater than 4.0 volts
- Oxygen sensor heater commanded off for an intrusive test
- O2 sensor signal drops below 4.0 volts
- Above conditions present for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
  - On second fault, freeze-frame data is stored
  - After two consecutive quick trips with a fault, MIL is illuminated.
  - MIL will extinguish after two consecutive normal trips without a fault
-



- 
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This DTC is set if the oxygen sensor signal shows significant interference by the oxygen sensor heater. This usually indicates either a wiring problem or a cracked or otherwise damaged sensor substrate.

### 3.203 DTC P2243 Oxygen Sensor Reference Circuit, Bank 1, Sensor 1

The ECM uses an oxygen sensor signal to measure the air-fuel ratio the engine is operating at. When using a UEGO sensor, the ECM supplies a 2.5 volt reference signal to which the pump cell and sensing cell are both connected to. If this signal does not remain at 2.5 volts, this DTC will set.

Flash code: none

Conditions to run test:

- Reference voltage output is more than 150 millivolts from the setpoint
- Condition exists for one second

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC usually indicates either a wiring fault or a cracked or otherwise damaged UEGO sensor. Check the wiring. If no problems found, change the sensor.

### 3.204 DTC P2261 Turbocharger Bypass Valve – Mechanical

In order to increase engine airflow, a turbocharger with a wastegate control system is commonly used on natural gas engines. A turbocharger bypass valve (dump valve) is sometimes used to limit the pressure rise when the throttle valve is quickly closed. If the control solenoid (if equipped) is functional, however, the boost pressure is not limited during a rapid deceleration, this DTC will set.

Typical causes of this include disconnected bypass valve control hoses, incorrect bypass valve part number, or a perforated bypass valve diaphragm.

Flash code: none

Conditions to run test:

- Under engine loaded conditions, engine boost level above a programmed limit

- 
- Engine speed above a programmed RPM (typically ½ of rated engine speed)
  - Minimum commanded load of 80%
  - Engine deceleration command to closed-throttle in less than 250 ms.
  - Boost pressure remains above a programmed limit
  - Condition exists for one second

Actions taken when fault is detected:

- Turbocharger boost control solenoid is set to minimum boost setting
- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check boost sensor connections to ensure boost (upstream of throttle) pressure is sensed.
- Check turbocharger, intercooler, bypass valve, and throttle plumbing for disconnected hoses or leakage.
- Check turbocharger bypass valve for leakage past the vacuum diaphragm by applying vacuum to the control port and ensuring that the vacuum does not leak down quickly.
- Ensure the replacement bypass valve is of high quality and the correct pressure setpoint.

### **3.205 DTC P2262 Turbocharger Boost Pressure - Mechanical**

In order to increase engine airflow, a turbocharger with a wastegate control system is commonly used on natural gas engines. If the turbocharger or wastegate do not respond correctly to the ECM control signals, or if mechanical problems exist in the wastegate control system, the engine may receive no boost pressure, which may result in low engine power output. This DTC indicates that this condition exists.

Typical causes of this include disconnected engine air intake hoses, a dislodged sensor, or a seized turbocharger. It is possible that a boost pressure sensor that is referencing atmospheric pressure may set this DTC.

Flash code: none

Conditions to run test:

- 
- Boost pressure duty cycle above 97.5% duty cycle (commanding higher boost)
  - Engine speed above a programmed RPM (typically ½ of rated engine speed)
  - Minimum commanded load of 80%
  - No more than 15 kPa<sub>g</sub> of boost pressure
  - Condition exists for three seconds

Actions taken when fault is detected:

- Turbocharger boost control solenoid is set to minimum boost setting
- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check boost sensor connections to ensure boost (upstream of throttle) pressure is sensed.
- Check turbocharger, intercooler, and throttle plumbing for disconnected hoses or leakage.
- Ensure turbocharger blades spin freely. Do not check this with the engine running. Turbocharger blades spin very quickly and can cause serious bodily damage.
- If checking the turbocharger, be careful not to damage the turbocharger turbine or compressor. Even a slight bend or nick in a turbocharger blade may cause catastrophic turbocharger failure.
- Often, catastrophic turbocharger failure will cause engine damage or failure. Ensure all air intake components are cleaned fully after such a failure.

### **3.206 DTC P2263 Turbocharger Boost Pressure System Performance**

In order to increase engine airflow, a turbocharger with a wastegate control system is commonly used on natural gas engines. If the turbocharger or wastegate do not respond correctly to the ECM control signals, or if mechanical problems exist in the wastegate control system, the engine may receive low boost pressure, which may result in low engine power output. This DTC indicates that this condition exists.

Flash code: none

Conditions to run test:

- 
- Boost pressure duty cycle either below 2.3% or above 97.5%
  - Engine speed above a programmed RPM (typically ½ of rated engine speed)
  - Minimum commanded load of 80%
  - More than 15 kPa<sub>g</sub> of boost pressure
  - Boost pressure did not reach within 25 kPa<sub>g</sub> of commanded boost pressure
  - Condition exists for three seconds

Actions taken when fault is detected:

- Turbocharger boost control solenoid is set to minimum boost setting
- Maximum desired manifold pressure is set to 100 kPa<sub>a</sub>

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check boost sensor connections to ensure boost (upstream of throttle) pressure is sensed. Check the hoses (if used) for good condition.
- Check turbocharger, intercooler, and throttle plumbing for disconnected hoses or leakage.
- Ensure turbocharger blades spin freely. Do not check this with the engine running. Turbocharger blades spin very quickly and can cause serious bodily damage.
- If checking the turbocharger, be careful not to damage the turbocharger turbine or compressor. Even a slight bend or nick in a turbocharger blade may cause catastrophic turbocharger failure.
- Often, catastrophic turbocharger failure will cause engine damage or failure. Ensure all air intake components are cleaned fully after such a failure.

### **3.207 DTC P2270    Oxygen Sensor 2, Bank 1, Signal Stuck Lean**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. The post-catalyst oxygen sensor is used to maintain this air-fuel ratio to within 0.1%, as well as monitoring catalytic converter performance. If the voltage remains low but still in-range, this DTC will set. This DTC is likely caused by problems other than the oxygen sensor – exhaust leaks or misfires are likely causes.

---

Flash code: none

Conditions to run test:

- Engine operating in closed loop mode
- Oxygen sensor voltage under 0.073 volts
- Condition exists for 22 seconds
- Post-catalyst oxygen control mode enabled
- No previous P0131, P2191, P2187, P2192, P2188, P2178, P0134, P136, P137, P138, or P2177
- No MAP sensor fault detected
- No TPS fault detected
- No ECTS fault detected
- No IATS fault detected
- No misfiring fault detected
- No injector circuit fault detected
- No fuel level sensor fault detected
- Fuel storage quantity above 5%

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

### **3.208 DTC P2271      Oxygen Sensor 2, Bank 1, Signal Stuck Rich**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. For lowest emissions, the goal is for the air-fuel ratio to oscillate around lambda of approximately 0.995. The post-catalyst oxygen sensor is used to maintain this air-fuel ratio to within 0.1%, as well as monitoring catalytic converter performance. If the oxygen sensor signal is likely valid but reading rich continually, this DTC will set.

Flash code: none

Conditions to run test:

- Engine operating in closed loop mode

- 
- Post-catalyst oxygen control mode enabled
  - Oxygen sensor voltage above 0.830 volts
  - Condition exists for 22 seconds
  - No MAP sensor fault detected
  - No TPS fault detected
  - No ECTS fault detected
  - No IATS fault detected
  - No misfiring fault detected
  - No injector circuit fault detected
  - No fuel level sensor fault detected
  - No previous P0131, P0132, P2191, P2187, P2192, P2188, P2178, P0134, P136, P137, P138, or P2177

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

### **3.209 DTC P2297      Oxygen Sensor 1, Bank 1, Signal Stuck Rich During Deceleration**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. Some types of contamination or circuit failures can cause the sensor to read rich when the fuel is supposed to be off. In addition, a stuck-on or very leaky fuel injector may set this DTC. A typical contaminant is silicone sealant.

Flash code: none

Conditions to run test:

- Oxygen sensor is warm
- Oxygen sensor voltage above 0.350 volts
- Fuel cut enabled
- Condition exists for five seconds
- No MAP sensor fault detected
- No TPS fault detected



- 
- No ECTS fault detected
  - No IATS fault detected
  - No misfiring fault detected
  - No injector circuit fault detected
  - No fuel level sensor fault detected
  - Above 5% fuel storage quantity
  - No previous P0031, P0032, P0031, P0032, P0131, P2191, P2187, P2192, P2188, P2178, P0134, or P2177

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- This DTC usually will set if the oxygen sensor is contaminated with silicone sealant.

### **3.210 DTC P2299 Accelerator Pedal Position Sensor and Brake Switch Incompatible**

The ECM utilizes accelerator pedal position information to determine the driver's desired engine power output. Most systems will use at least two throttle position sensors for redundancy; however, some systems only use a single sensor and an idle switch. For developed markets, often a brake switch is used to provide a separate, redundant, indication that the driver wishes to slow the vehicle down.

If enabled, this DTC may set while performing certain high-speed or racing manoeuvres such as a brake stand or left-foot braking. For racing applications, this DTC should be disabled.

Flash code: none

#### Conditions to run test:

- No sensor power supply fault recorded
- Conditioned accelerator pedal position value is greater than 20%
- Brake switch input is activated
- Condition exists for one second

#### Actions taken when fault is detected in an ETC system:

- In most calibrations, driver's torque demand will be set to zero while the brake switch is active

- 
- In some calibrations, the accelerator pedal will be disabled after this has occurred

#### DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints:

- Ensure brake switch and accelerator pedal inputs work properly by testing with a scan tool.
- Poor (or racing) driving technique may cause this DTC to set.

### 3.211 DTC P2300 Ignition Coil 1 Circuit Primary Low Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

#### Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

#### DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

---

### 3.212 DTC P2301 Ignition Coil 1 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
- If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.213 DTC P2302 Ignition Coil 1 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather being sent back to the ECM at the end of the dwell time.

---

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

### **3.214 DTC P2303 Ignition Coil 2 Circuit Primary Low Current**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

### 3.215 DTC P2304 Ignition Coil 2 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long, or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).

- 
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
  - If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.216 DTC P2305 Ignition Coil 2 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather, being sent back to the ECM at the end of the dwell time.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.



---

### 3.217 DTC P2306 Ignition Coil 3 Circuit Primary Low Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

### 3.218 DTC P2307 Ignition Coil 3 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

---

- 
- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
  - The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
- If only one ignition coil exhibits this fault, replace that ignition coil.

### **3.219 DTC P2308 Ignition Coil 3 Circuit Secondary Fault**

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather being sent back to the ECM at the end of the dwell time.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

---

- 
- Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

### **3.220 DTC P2309 Ignition Coil 4 Circuit Primary Low Current**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

---

### 3.221 DTC P2310 Ignition Coil 4 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long, or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
- If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.222 DTC P2311 Ignition Coil 4 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather, being sent back to the ECM at the end of the dwell time.

---

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

### **3.223 DTC P2312 Ignition Coil 5 Circuit Primary Low Current**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

### 3.224 DTC P2313 Ignition Coil 5 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).



- 
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
  - If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.225 DTC P2314 Ignition Coil 5 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather being sent back to the ECM at the end of the dwell time.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

---

### 3.226 DTC P2315 Ignition Coil 6 Circuit Primary Low Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

### 3.227 DTC P2316 Ignition Coil 6 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long, or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

---

- 
- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
  - The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
- If only one ignition coil exhibits this fault, replace that ignition coil.

### **3.228 DTC P2317 Ignition Coil 6 Circuit Secondary Fault**

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather, being sent back to the ECM at the end of the dwell time.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

---

- 
- Immediate DTC stored
  - Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

### **3.229 DTC P2318 Ignition Coil 7 Circuit Primary Low Current**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

---

### 3.230 DTC P2319 Ignition Coil 7 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
- If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.231 DTC P2320 Ignition Coil 7 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather being sent back to the ECM at the end of the dwell time.

---

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

### **3.232 DTC P2321 Ignition Coil 8 Circuit Primary Low Current**

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not reach a current level of 2 amperes
- Fault occurrence count of 20

DTC Logic: Type A1.

- Immediate DTC stored



- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Ensure ignition power is available at the ignition coils
- Check the ignition coil primary resistance to ensure ignition coil is not damaged.
- Check wiring to the ignition coils

### 3.233 DTC P2322 Ignition Coil 8 Circuit Primary High Current

This diagnostic trouble code indicates that a wiring problem exists between the ECM and the ignition coil, or that the ignition coil is faulty, or that the programmed dwell time is too long, or that the ignition key power voltage is considerably lower in voltage than the power at the ignition coil. This can also occur if the switch-on spark suppression diode is open at low manifold pressure levels.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current reached a current level of 9.5 amperes prior to the expected end of dwell time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- This DTC may set if the ignition coil is connected backwards (+ and – leads swapped).

- 
- This DTC may set if the key power signal to the ECM is significantly lower in voltage than the power supplied to the ignition coils.
  - If only one ignition coil exhibits this fault, replace that ignition coil.

### 3.234 DTC P2323 Ignition Coil 8 Circuit Secondary Fault

This diagnostic trouble code indicates that a wiring problem exists between the ignition coil and the spark plug. Only an open circuit can be diagnosed; a short circuit, cracked spark plug, degraded wire insulation cannot be diagnosed via this DTC. A misfire fault without a corresponding ignition system fault is an indication of this type of problem. This is diagnosed by detecting the ignition energy not being delivered to the spark plug, but rather, being sent back to the ECM at the end of the dwell time.

Flash code: none

Conditions to run test:

- No actuator power supply faults recorded
- Actuator power relay actuated
- Ignition current did not decay to a current level of 2 amperes prior to the expected end of current decay time
- Fault occurrence count of 20

Actions when the fault occurs:

- The dwell time is reduced for that ignition coil, then lengthened slowly until the fault occurs again.
- The first few spark events with this fault set will occur earlier than desired (more advance)

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check the ignition secondary wiring and spark plug for open circuits.
- Check the spark plugs for excessively worn electrodes.

---

### 3.235 DTC P2336     **Cylinder 1 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### 3.236 DTC P2337     **Cylinder 2 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent

---

---

knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### **3.237 DTC P2338     Cylinder 3 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

---

---

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### **3.238 DTC P2339     Cylinder 4 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

---

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### **3.239 DTC P2340     Cylinder 5 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately



- 
- MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high effective octane rating to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### 3.240 DTC P2341      **Cylinder 6 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

#### Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.

- 
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
  - Check engine for mechanical noise.
  - Ensure turbocharger system operates correctly.

### **3.241 DTC P2342     Cylinder 7 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

---

### 3.242 DTC P2343     **Cylinder 8 Above Knock Threshold**

Engine knocking is very destructive. Knocking is caused by excessive cylinder pressure and temperature causing an uncontrolled burn of the air/fuel mixture. On natural gas engines, the typical causes of engine knock are excessive boost pressure, poor fuel anti-knock quality, and high inlet air temperatures. On lean-burn engines only, a rich mixture may cause engine knock. To help prevent knock damage, a knock sensor can be used to determine if the engine is knocking, and to take remedial action. This includes retarding ignition timing and reducing maximum engine torque. If these measures do not reduce engine knock quickly, engine damage will occur from the excessive pressure and temperature buildup. Note that while the engine is knocking, exhaust temperature will typically fall, so exhaust temperature monitoring is ineffective at stopping this.

The ECM typically is calibrated to separately retard timing on a per-cylinder basis.

Flash code: none

Conditions to run test:

- Knock timing is retarded against its maximum limit for this cylinder
- Condition exists for 10 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check fuel quality. Turbocharged engines may require a high anti-knock index (effective octane rating) to avoid preignition.
- Check intercooler for proper performance. Intake air temperature must remain below the engine manufacturer's specified limit.
- Check engine for mechanical noise.
- Ensure turbocharger system operates correctly.

### 3.243 DTC P2428     **Exhaust Overheat**

Operating the engine with excessive exhaust temperature may result in engine, turbocharger, or catalyst damage. This DTC is set when the engine is operated with an excessive exhaust temperature. The maximum exhaust temperature is engine and catalyst dependant.

Flash code: none

---

---

Conditions to run test:

- Exhaust temperature is above a programmed threshold (typically about 900 degrees C)
- Condition exists for 15 seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check for proper turbocharger and throttle control
- Check ignition timing
- Check exhaust backpressure
- Check catalyst for clogging or damage

### **3.244 DTC P2560 Engine Coolant Level Low**

Operating the engine with excessive coolant temperature or a low coolant level may result in engine damage. In many cooling systems, an engine overheat will not be detected due to a loss of coolant via the engine coolant temperature sensor. This DTC is set when the engine is operated with a low coolant level when a low coolant level probe or switch is used.

Flash code: none

Conditions to run test:

- Engine has been running for at least two minutes
- Coolant probe signal indicates coolant level is low

DTC Logic: Type C3

- Pending DTC will be stored
- MIL will not illuminate for this fault type
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check engine coolant level manually.
- If coolant level is sufficient, check wiring and sensor / switch.

---

### 3.245 DTC P2626    **Oxygen Sensor 1, Bank 1, Trim Circuit Open**

The ECM utilizes lambda sensor voltage to determine the air-fuel ratio of the engine. A UEGO cell requires factory trimming to accurately measure air-fuel ratio. This diagnostic is intended to check for an open circuit in the trim line.

Flash code: none

Conditions to run test:

- UEGO cell is warm
- Sensor pump output is greater than 3.6 volts or less than 1.4 volts
- Condition exists for five seconds

DTC Logic: Type B

- On trip with first fault, pending DTC stored
- On second fault, freeze-frame data is stored
- After two consecutive quick trips with a fault, MIL is illuminated.
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints

- Check UEGO wiring for proper connections.
- If all connections appear ok, change the UEGO sensor.

### 3.246 DTC P2666    **Fuel Shutoff B Solenoid Circuit Low**

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fuel Shutoff Solenoid B commanded off
- Output driver IC records low voltage fault (short to ground or open load)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored

- 
- Stores freeze-frame data at time of fault
  - MIL illuminates immediately
  - MIL will extinguish after two consecutive normal trips without a fault
  - DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.

### **3.247 DTC P2667 Fuel Shutoff B Solenoid Circuit High**

The control circuit to the fuel shutoff solenoid is tested for continuity. A faulty solenoid or wiring problems will typically cause this DTC to set.

Flash code: none

Conditions to run test:

- Key power voltage greater than 6 volts
- Actuator power control relay commanded on
- Fuel shutoff solenoid B output commanded on
- Output driver IC records high voltage fault (short to power)
- Conditions exist for 0.3 seconds

DTC Logic: Type A1.

- Immediate DTC stored
- Stores freeze-frame data at time of fault
- MIL illuminates immediately
- MIL will extinguish after two consecutive normal trips without a fault
- DTC will clear after forty consecutive normal trips without a fault

Troubleshooting Hints:

- Verify continuity and resistance of the solenoid coil
- Verify wiring between solenoid and ECM
- Verify actuator power (controlled by main actuator power control relay) is available at the fuel shutoff control solenoid.



---

### 3.248 DTC U1110 Antitheft Module Triggered

If the engine control module has not received a correct antitheft fuel enable signal, this DTC will set and fuel will be disabled.

Flash code: none

Conditions to run test:

- Key power above 6 volts
- Engine fuel enable signal not present
- Condition exists for 5 seconds

DTC Logic: Type C1.

- Immediate DTC set
- No freeze-frame data will be stored
- DTC will clear after forty consecutive normal trips without a fault

## 4 MODE 6 DATA GUIDE

This chart shows the available mode 6 data applicable to the A36 control module. These parameters may be accessed using an OBD scan tool. Readiness status indicators (mode 1, PID 1) may be used to verify that the appropriate diagnostic tests have run. If the tests have not run, displayed data will be shown as '0' and the readiness indication will indicate 'Test Not Complete'.

TID	Test	Test Description	Offset	Scale	Units
0x01	0x07	Lean O2 voltage too high (lower = pass)	0	0.005	Volts
0x01	0x08	Rich O2 voltage too high (leakage to battery power)	0	0.005	Volts
0x01	0x88	Rich O2 voltage too low	0	0.005	Volts
0x01	0x09	Transition time too high	0	0.04	Seconds
0x01	0x89	Transition time too low	0	0.04	Seconds
0x01	0x41	Switch ratio staying rich too long	128	1/128	Ratio
0x01	0xc1	Switch ratio staying lean too long	128	1/128	Ratio
0x41	0x01	Oxygen sensor impedance test	0	100	Ohms
0x41	0x02	Time to enter warmed-up mode	0	1	Seconds
0x39	0xf1	Large fuel leak test pressure ratio	0	1/256	Ratio
0x39	0xf2	Small fuel leak test pressure ratio	0	1/256	Ratio

---

## APPENDIX A: YOUR ATMOSPHERIC PRESSURE

---

The atmospheric pressure depends primarily on the altitude of the observer. In the case of an engine management system, the observers are pressure sensors located on the engine. These sensors measure pressure in absolute units, where a pressure of zero indicates no air pressure at all – outer space - and an air pressure of 101.325 kPa<sub>a</sub> indicates an air pressure found at sea level under standard atmospheric conditions.

In order to verify the readings of these sensors, a calculation based on altitude is required. Refer to the following table for the approximate pressure based on altitude. Finer corrections are possible if a barometer is used to correct these values. To correct the values to a local barometer, add this pressure to the barometer reading, then subtract 101.325 kPa from the sum.

Altitude (m)	Altitude (ft)	Pressure (kPa Absolute)
0	0	101.325
230	700	98
450	1500	96
600	2000	94
800	2600	92
1000	3200	90
1200	3900	88
1400	4600	86
1600	5200	84
1800	5900	82
2000	6500	80
2200	7200	78
2400	7800	76
2600	8500	74
2800	9200	72
3100	10000	69
3400	11000	66
3800	12500	63
4200	14000	60